

BETA MARINE

Operator's Maintenance Manual




Heat Exchanger & Keel Cooled

**Small Diesel Engine Range: Beta 10,
Beta 14, Beta 16, Beta 20 & Beta 25**

CALIFORNIA - Proposition 65 Warning: Diesel engine exhaust and some of its constituents are known to the state of California to cause cancer, birth defects and other reproductive harm.

Fig 1 Typical Heat Exchanger Cooling System



Contents

Engine details (to be completed now)	1
Introduction	3
Engine identification	4
Initial receipt of the engine	4
Engine storage	4
Safety precautions	5
Technical specifications	6
SECTION 1: INSTALLATION GUIDELINES	7
Engine mounting	8
Engine alignment - drives, flanges, flexible couplings	9
Exhausts and mounting exhausts	11
Cooling - sea water inlet system	14
Fuel supply and "leak off"	18
Calorifier connections (if fitted)	19
Electrical installation	22
SECTION 2: GUIDELINES FOR OPERATION OF THE ENGINE	26
Important checks prior to initial use	26
Initial start-up and bleeding the fuel system	26
Starting and stopping	28
SECTION 3: MAINTENANCE & SERVICE GUIDELINES	31
Maintenance schedule	32
Lubrication - checking and changing oil	33
Fuel system - fuel / water separator, fuel lift pump, fuel filter	36
Cooling - fresh water system, heat exchanger	37
Sea water pump, heat exchanger	38
Tube stack and 'wasting zinc anode'	40
Belt tensioning adjustment	41
Air filter inspection / replacement	42
Electrical maintenance	42
Laying up - winterising	43
Troubleshooting	44
Torque settings	55
Wiring diagrams and general arrangement drawings index	56
Exhaust emission - declaration of conformity	91
Exhaust emission - durability	92
Quick reference parts list	93
Maintenance record	96

OPERATION AND MAINTENANCE MANUAL FOR THE FOLLOWING BETA MARINE ENGINES BASED ON KUBOTA

Beta 10, Beta 14, Beta 16, Beta 20 & Beta 25

WELCOME TO BETA MARINE

Thank you for purchasing a Beta Marine Engine. We have made this manual to provide you with important information and recommendations to ensure trouble free and economical operation of the engine.


As manufacturers we have obviously written this “Operators Maintenance Manual” from our ‘involved technical viewpoint’ assuming a certain amount of understanding of marine engineering. We wish to help you, so if you do not fully understand any phrase or terminology or require any explanations please contact Beta Marine Limited or its distributors and we will be pleased to provide further advice or technical assistance.

All information and recommendations given in this publication are based on the latest information available at the time of publication, and are subject to alteration at any time.


The information given is subject to the company’s current conditions of Tender and Sale, is for the assistance of users, and is based upon results obtained from tests carried out at the place of manufacture and in vessels used for development purposes. We do not guarantee the same results will be obtained elsewhere under different conditions.

▼ ENGINE IDENTIFICATION

⚠ IMPORTANT! - We are asking you to always provide the **WOC (Works Order Card number and or the engine serial number)** in all communications concerning your engine



▼ BETA 10, BETA 14, BETA 16, BETA 20 & BETA 25



The engine serial number is shown on the rocker cover label. It is also stamped on the crank case flange below the fuel injection pump on the starboard side of the engine.

▼ INITIAL RECEIPT OF THE ENGINE

A full inspection of the engine must be made **immediately on delivery** to confirm that there is no damage. If there is any damage then write this clearly on the delivery note and inform your dealer or Beta Marine within 24 hours. A photograph would always help.

▼ ENGINE STORAGE

The engine must be stored in a dry, frost free area and this is best done in its packing case. If storage is to be more than six months then the engine must be inhibited (contact your dealer or Beta Marine). Failure to inhibit the engine may result in the formation of rust in the injection system and the engine bores, this could invalidate the warranty.



Safety Precautions!

A Keep the engine, gearbox and surrounding area clean, including the area immediately below the engine.

B Drives - Power Take Off Areas

i) Gearbox Output Flange

The purpose of a marine diesel propulsion engine is to provide motive power to propel a vessel. Accordingly the gearbox output shaft rotates at between 280 and 2400 rev/min. This flange is designed to be coupled to a propeller shaft by the installer and steps must be taken to ensure adequate guarding.

ii) Forward End Drive

Engines are supplied with unguarded belt drives to power the fresh water pump and battery charging alternator. The installer must ensure that it is not possible for injury to occur by allowing access to this area of the engine. The three pulleys run at high speed and can cause injury if personnel or clothing come in contact with the belts or pulleys, when the engine is running.

iii) Power Take Off Shaft (Engine Mounted Option)

Shaft extensions are available as an option and rotate at between 850 and 3600 rev/min. If contact is made with this shaft when the engine is running, injury can occur.

C Exhaust Outlet

Diesel marine propulsion engines emit exhaust gases at very high temperatures - around 400 - 550°C. Engines are supplied with either wet exhaust outlet (water injection bend) or dry outlet (dry exhaust stub) - see option list. At the outlet next to the heat exchanger/header tank, the exhaust outlet can become very hot and if touched, can injure. This must be lagged or avoided by ensuring adequate guarding. It is the responsibility of the installer to lag the exhaust system if a dry system is used. Exhaust gases are harmful if ingested, the installer must therefore ensure that exhaust pipes are led overboard and that leakage in the vessel does not occur.

D Fuel

i) Fuel Lines

Diesel engines are equipped with high pressure fuel injection pumps, if leakages occur, or if pipes fracture, fuel at a high pressure can harm personnel. Skin must be thoroughly cleaned in the event of contact with diesel fuel.

ii) Fuel Supply Connections

Engines are supplied with 8mm compression fittings. The installer must ensure that when connections are made, they are clean and free of leaks.

E Oil

The Beta propulsion unit is supplied with 2 dipsticks, one for the engine and one for the gearbox. Ensure dipsticks are returned and secure after checking, if not oil leaks can cause infection when touched. All oil must be removed from the skin to prevent infection.

F Scalding

An engine running under load will have a closed circuit fresh water temperature of 85° to 95°C. **The pressure cap on the top of the heat exchanger must not be removed when the engine is running.** It can only be removed when the engine is stopped and has cooled down.

G Transportation / Lifting

Engines are supplied on transportable pallets. Lifting eyes on engines are used for lifting engine and gearbox assembly only, not the pallet and associated kit.

GENERAL DECLARATION

This machinery is not intended to be put into service until it has been incorporated into or with other machinery. It is the responsibility of the purchaser / installer / owner, to ensure that the machinery is properly guarded and that all necessary health and safety requirements, in accordance with the laws of the relevant country, are met before it is put into service.

Signed:

J A Growcoot, C.E.O, Beta Marine Limited.

NOTE: Recreational Craft

Where applicable, the purchaser / installer / owner and operator must be responsible for making sure that the Recreational Craft Directive 94/25/EC is complied with.

Technical Specifications

Standard Engines		Beta 10	Beta 14	Beta 16	Beta 20	Beta 25
Cylinder		2	2	2	3	3
Bore (mm)		67	67	72	67	72
Stroke (mm)		68.0	68.0	73.6	68.0	73.6
Displacement (cc)		479	479	599	719	898
Combustion		3 Vortex, naturally aspirated, indirect injection				
Power Output EN ISO 8665	kW	8.0	9.5	12.0	14.3	17.8
	at rev/min	3,000	3,600	3,600	3,600	3,600
Maximum Torque	N m	29.7	29.7	37.8	45.8	56.1
	at rev/min	2,600	2,600	2,600	2,600	2,400
Capacity of standard sump (litres)		2.0 - 2.5	2.0 - 2.5	2.4 - 2.9	3.1 - 3.8	3.7 - 4.5
Capacity of shallow sump (litres)		2.2	2.2	2.6	3.4	3.8
Nett dry weight with gearbox (kg)		89	90	95	104	113
Fuel		Diesel fuel oil to EN 590 or ASTM D975				
Coolant		50% antifreeze : 50% water				
Coolant capacity approx. (H/E litres)		2.25	2.25	2.25	3.00	3.25
Electric starting - standard		12 Volt				
Starter motor output (kW)		0.8	0.8	1.0	0.8	1.2
Alternator (battery charging) standard		40 Amps				
Min. recommended battery capacity		12 Volt, 45 Ah (400 CCA Minimum)			70 Ah (500 CCA)	

Maximum Angle of Installation: 15° flywheel up or flywheel down when static; and up to 25° when heeling.

Rotation: Anti-clockwise on flywheel, clockwise on output gearbox output flange - for use with right hand propeller in ahead, with mechanical gearboxes. Hydraulic gearboxes can be left or right handed.

Fuel: Diesel fuel must conform to EN590 or ASTM D975.

Engine Lubrication: Engine oil must meet API Classification CF (CD or CE have been superseded by CF).

Gearbox Lubrication: See gearbox operator's manual for the gearbox oil type and capacity.

Oil Pressure: Minimum (tickover) 0.5 bar.

Power Outputs: These comply with EN ISO 8665 propeller-shaft power.

1. Declared powers are measured at the gearbox output flange (as coupled to the propeller shaft) as per EN ISO 8665, developed from our standard engine specification, including gearbox and accessories as detailed in our current price lists. Additional accessories or alternative gearboxes may affect the declared powers. Declared power outputs are subject to the stated tolerance band.
2. Operation at parameters outside the test parameters may affect the outputs / powers.

Section 1

▼ INSTALLATION RECOMMENDATIONS

The installation details are basic guidelines to assist installation, however due to the great diversity of marine craft it is impossible to give definitive instructions. Therefore Beta Marine can accept no responsibility for any damage or injury incurred during the installation of a Beta Marine Engine whilst following these guidelines.

- All engines shall be placed within an enclosure separated from living quarters and installed so as to minimise the risk of fires or spread of fires as well as hazards from toxic fumes, heat, noise or vibrations in the living quarters.
- Unless the engine is protected by a cover or its own enclosure, exposed moving or hot parts of the engine that could cause personal injury shall be effectively shielded.
- Engine parts and accessories that require frequent inspection and / or servicing must be readily accessible.
- The insulating materials inside engine spaces shall be non-combustible.

▼ VENTILATION

The engine compartment needs air.

- a) as air (oxygen) to burn the diesel fuel, and
- b) as air to keep the engine cool (still hot at 100°C) by ventilation.

It is important that the engine compartment has adequate ventilation, and **this is your responsibility**. If there is no ventilation the engine can overheat and damage can be caused. As a general statement an engine will produce radiated heat - approximately equal to $\frac{1}{3}$ of the engine output power. Also the larger battery charging alternators create lots of heat. (A symptom of overheating problems is often black belt dust). If you have any doubts about

the temperature of your engine compartment please check with a thermometer on a hot day, the maximum temperature in the engine compartment should be less than 70°C - the cooler the better!

Engine compartment ventilation is normally best with two holes; an **inlet** allowing colder air to enter below to the alternator and drive belts and a second **outlet** (about the same size) for the hot air to rise and ventilate out from the top of the engine compartment. Adequate ventilation must be included with all installations. Installations require a good quality reliable electric ventilation fan wired into the ignition switch to remove the hot air. The required air flow volumes in $\text{m}^3/\text{min} = 0.05 \times \text{engine power in hp}$.

Typical ventilation sizes

	10hp	20hp	30hp	40hp	50hp	75hp	100hp	150hp
Combustion	14 cm ²	28 cm ²	43 cm ²	57 cm ²	71 cm ²	106 cm ²	142 cm ²	213 cm ²
Ventilation	13 cm ²	25 cm ²	37 cm ²	50 cm ²	62 cm ²	92 cm ²	123 cm ²	185 cm ²
Inlet / Outlet dia.	6 cm	9 cm	11 cm	12 cm	13 cm	16 cm	19 cm	22 cm

▼ INSTALLATION RECOMMENDATIONS FOR KEEL COOLED ENGINES

Keel cooled engine overheating is sometimes caused by:

- a) Not fully venting the engine cooling system of air. It is necessary to remove all air from the cooling system - including the "skin" tanks and (if fitted) the Calorifier and associated piping.
- b) Incorrectly sized "skin" tanks that have been sized for 'usual' canal use, rather than maximum engine output that can sometimes be required on fast flowing rivers. An additional "skin" tank may need to be fitted; please refer to our website: Inland waterways - guidelines: keel cooling tank sizes.


▼ ENGINE MOUNTING

To ensure vibration free operation, the engine must be installed and correctly aligned on substantial engine bearers, extending as far forward and aft as possible, well braced and securely fastened to form an integral part of the hull.

The engine must be installed as low as possible on the flexible mount pillar stud. This will limit vibration and extend the life of the flexible mount. To assist with engine replacement we offer 'Special Engine Feet' manufactured to your dimensions, as an optional extra to suit your existing engine bearers and shaft alignment / installation.


⚠ WARNING!

- Do not set the engine feet high up the flexible mount pillar stud. This will cause excessive engine movement and vibration. Pack steel shims under the flexible mount and ensure that the flexible mounting is securely bolted to the engine bearer.




- The pillar stud on the flexible mount is secured into position by the lower locknut, do not forget to tighten this. **Also ensure that the stud is not screwed too far through the mounting body so that it can touch the bearer. This will cause vibration and knocking noises which are very hard to find!** If the flexible mounting is too far offset then the loading on the flexible mounting will cause premature failure, modifications are needed.

5 Engine Mount Alignment




Recommended

Correct height and positioning




Acceptable

Shim(s) required to achieve correct height and positioning



NOT Recommended

Positioning too high on the pillar stud - requires shims



NOT Acceptable

NOT aligned - requires bearer modifications to correct

▼ ENGINE INSTALLATION AT AN ANGLE

Beta Marine propulsion engines can be installed at angles up to a maximum of 15° flywheel up or flywheel down when static, and can be run at up to 25° when heeling. However if you are considering installing above 12° please contact Beta Marine or alternatively consider the 7° down angle gearbox. When our engines are installed at varying angles of inclination the normal markings on the dipstick




should be disregarded. It is probably better to totally drain the sump, and completely refill the engine sump with the recommended quantity / volume of lubricating oil - noting its position on the dipstick - and then marking the dipstick accordingly (don't forget to replace the oil filter). **If in doubt ask Beta Marine!**

▼ ALIGNMENT




To obtain accurate alignment the flexible mountings must be adjusted until alignment is attained, and the mountings must be locked in position. The engine / gearbox unit has to be aligned with the propeller shaft in two ways. The traditional engine alignment method involves measuring with either feeler gauges or a DTI (Dial Test Indicator)

mounted on a magnetic foot so that they are aligned within 0.125mm (0.005"). (Obviously the propeller shaft must be centered in the stern tube and running true - through the cutless bearing; if the propeller shaft is not correctly centered you will experience vibration).

ANGULAR ALIGNMENT



PARALLEL ALIGNMENT



The engine mountings and the couplings must now be tightened in position and the alignment re-checked.

▼ FLEXIBLE OUTPUT COUPLINGS


A flexible coupling is mounted on the gearbox output flange and is strongly recommended in almost every case. Flexible couplings do not resolve bad alignment, they are designed to absorb torsional vibrations from the propeller (transmitted along the propeller shaft).

We normally offer two types:

R&D with a flexible nylon disc and optional Clamp Coupling – a very good economical solution.



The excellent 'CentaFlex' coupling design includes lots of rubber to absorb torsional shocks and loads. The 'CentaFlex' coupling is complete, replacing both the R&D flexible and the R&D clamp couplings above.



▼ EXHAUST SYSTEMS

There are two main types of exhaust system:

- 1) Standard yacht - wet exhaust system with a water injection bend and waterlock silencer
- 2) Dry exhaust system (see page 17)

We recommend care when designing your exhaust system. The most important aspect is to ensure that water cannot enter the engine's combustion chamber from the exhaust system (this applies to both wet and dry exhaust systems).

▼ STANDARD YACHT - WET EXHAUST INSTALLATION


Owners need to be aware of three major problems that can easily occur when installing an engine in a sailing yacht or motor boat and allowing the engine to 'hydraulic lock'.

- Seawater syphoning past worn impellers in the seawater pump, flooding the exhaust system, and back filling into the combustion chamber when the engine is stopped.
 - Seawater washing into the combustion chamber from the exhaust system due to either a very shallow exhaust run from the injection bend to the waterlock silencer, or because the waterlock silencer is too small to accept the total amount of cooling water in the exhaust hoses, or both. This can happen when the yacht is sailing into a big sea and a surge is set up in exhaust system as the yacht pitches - with the engine switched off.
- Waves forcing water up the exhaust due a poorly designed system with no 'gooseneck'. Small work boats moored on exposed beaches are very vulnerable to this as waves hit the stern before the boat can swing into the wind on a rising tide.

It is therefore very important to ensure that the engine will not 'hydraulic lock'. This can be a problem with engine installations. When water enters the combustion chamber and 'hydraulics' against the rising piston, a bent con rod, emulsified engine oil and a wrecked fuel pump can be the result. It's best avoided!

If your engine is installed below the water line, the potential for water entering the engine is considerably increased. The important dimension that must be measured is from the normal 'static' sea level to the point at where the cooling water is injected into the exhaust - this should be a minimum of 25 cms. If this can not be achieved the following options must be taken (see 11, 12 and 13).

11 Standard Exhaust System



▼ HIGH-RISE EXHAUST



In yachts, engines are mostly installed low down and often below the water line. There are several ways to avoid cooling water entering the engine.

Syphoning of cooling water can occur when the rubber impellor of the sea water pump becomes worn. If our

standard injection bend is too low then we can offer a high-rise injection bend that adds 15 cms to the height.

If this is still not enough then you have to fit an 'antisiphon' / vacuum valve 50 cms above the 'loaded' water line sea level (see 13 below).

12 Exhaust with High Rise



▼ EXHAUST WITH ANTI-SYPHON VALVE

When the engine is installed with the standard injection bend - and the water injection point is still less than 25 cms above the 'static' seawater level or is below it, then you should either install a high rise injection bend adding 15 cms to the height or an anti-syphon valve to resolve the problem.



Some installers will always fit an 'Anti-Syphon' valve in yachts, regardless of the position of the injection bend - just to be as safe as possible. When fitting an anti-syphon

valve to a yacht, it must be mounted as near as possible to the centerline so that there is no possibility that the valve goes under the water line when the yacht heels over.

⚠ IMPORTANT!

These valves need to be checked regularly as they have been known to block up with salt crystals over time.

13 Exhaust with Anti-syphon Valve




▼ WATERLOCK / SILENCER

You must always fit a waterlock / silencer to stop any water in the exhaust system back filling the engine. The water lock should always be fitted at least 30 cms away from the injection bend and at least 30 cms below the

injection bend, being as low as reasonably possible, so that all the water can drain down into it. The waterlock should have sufficient capacity to hold an exhaust system full of water - draining into it.

14 Waterlock / Silencer Positioning



You should always create a 'gooseneck' with the exhaust hose (or purchase a propriety one) by raising the exhaust hose 40 cms above the waterline before exiting the transom at least 5 cms above the waterline. This will stop any waves pushing seawater down the exhaust.

Position of silencer in relation to exhaust hose length:


Length (L)	Height (H)
30 cm	30 cm
120 cm	40 cm

⚠ IMPORTANT!


If measurement 'H' cannot be met, a high rise exhaust injection bend must be installed so that any residual water flows / drains into the waterlock / silencer or overboard.

With longer lengths of exhaust hose you may need to support the hose to avoid a drooping hose and water build up.

15 Exhaust Hose 'Gooseneck'



16 Exhaust 'Gooseneck'



▼ SEA WATER INLET FOR HEAT EXCHANGER COOLED ENGINES


Your engine is fitted with a gear driven sea water pump which sucks in seawater (raw water) to cool the closed circuit system via the heat exchanger.

Engine	Seacock Inlet / Seawater Pump Hose I.D.
Beta 10 to Beta 38	19 mm (3/4") min.
Beta 43 to Beta 60	25 mm (1") min.
Beta 75 to Beta 105	28 mm (1 1/4") min.

1. It is very important that the seawater inlet should have a strainer system either 'A' built into the sea cock, or 'B' a high level system with visual inspection glass (as

- shown) mounted just above the water line.
2. Good access to the inlet sea cock from inside your boat is essential so that plastic bags or seaweed trapped in the intake can be poked out.
3. All pipe work should have approved marine grade stainless steel hose clips. Any loose clamps or bad connections can cause flooding and sinking of the vessel. It is accepted practice that two stainless steel clips should be used at each end of raw water pipes for security. Ensure that you use the correct grade of hose.



Note: The maximum lift of the sea water pump is 2m when primed.




4. A normal inlet sea cock type 'A' (as shown in 17 above) is recommended as this can be 'rodded out' to remove blockages. We do not recommend the use of 'Scoop' type water pickups, because if fitted the wrong way around the water will be forced through the

pump and into the exhaust system whilst the vessel is sailing. This is very dangerous as the exhaust will eventually fill and sea / raw water will back up into the engine through the exhaust valve. Catastrophic failure will result as soon as the engine is restarted.

18 Sea Water Inlet - Scoop




▼ STERN GEAR LUBRICATION




⚠ IMPORTANT! - ENGINE COOLING

If a 'water feed take off' is required for stern gear lubrication of the cutlass bearing or if you have an anti-syphon valve with 'continuous bleed', then the connection must be taken **after** the heat exchanger (**not** before) and the maximum size should be an 1/8 inch BSP fitting with a 5mm hose.

(Installations that have excessive water 'bleed' will effect combustion temperatures and exhaust emissions; and taken to the extreme could either seize the engine and/or melt the exhaust system).



Beta 10 to Beta 60 - can be connected to the heat exchanger end cap using our 'Stern Bleed kit' and drilling and tapping the end cap.




Beta 75 upwards - need a 'T' piece with an 1/8" BSP connection fitted just after the heat exchanger as shown in the drawing. It is important that this 'feed' is taken from the engine side of an anti-syphon valve or you can 'hydraulic' the engine with catastrophic results.

▼ PROPELLER CLEARANCE

There must be a propeller clearance between the tip of the propeller blade and the underside of the hull.

This should be a minimum of 10% of the diameter of the propeller (some say 15%) to reduce 'tip noise'.

22 Propeller Clearance



▼ EXHAUST HOSE

Wet exhaust hose should be matched to the injection bend diameter. An engine correctly installed in accordance with this handbook will meet the emission requirements of the RCD (Recreational Craft Directive).

Engine	Exhaust Hose I.D.
Beta 10 to Beta 60	50 mm
Beta 75 & Beta 90	60 mm
Beta 105	75 mm

▼ EXHAUST BACK PRESSURE

Keep exhaust systems to a minimum length and have gradual bends (NOT right angle elbows). Exhaust back pressure should be as low as possible; it is increased by long exhaust length and sharp bends. Back pressure should be measured with the complete exhaust system connected and the engine running at full speed. The correct measuring point is before the injection bend (at the manifold flange). We can supply a Manometer kit for testing 'Back Pressure'.


Engine	Exhaust Back Pressure
Beta 10 to Beta 25	Max. 70 mm Hg
Beta 30 to Beta 60	Max. 80 mm Hg
Beta 75 & Beta 90	Max. 90 mm Hg
Beta 105	85 to 115 mmHg

▼ DRY EXHAUST INSTALLATION


- a) An engine correctly installed in accordance with this handbook will meet the emission requirements of the RCD (see back of manual).
 - b) Keep exhaust systems to a minimum length and have gradual bends, refer to 'exhaust back pressure' bottom of page 16 for further information.
 - c) The dry exhaust system installed in a canal boat or work boat should be 1½" minimum internal diameter.
- The engine is fitted with a 1½" BSP male connector stub as standard - Valid for exhaust systems up to 3 metres in length. A flexible exhaust bellows and dry exhaust silencer should be used. It is up to the installer to work out his own pipe run but care should be taken as follows:

- Never use a flexible exhaust bellow as a bend, it will crack, always keep them straight.
- Ensure that rain water (or any other water - say from the side of the loch) cannot enter the exhaust port and run back down the system, flooding the silencer and eventually the engine (see drawings below).
- The system should be lagged if there is any danger of the crew getting near it.
- A dry exhaust system will give off considerable heat and suitable insulation and ventilation must be provided.

23 Dry Exhaust System




24 Dry Exhaust System



Ensure exhaust raises then falls to outlet

▼ FUEL SUPPLY & LEAK OFF

25 Fuel Supply and Leak Off



NOTES:

1. A fuel / water separator must be installed.
2. The mechanical fuel lift pump is fitted to all engines as standard, but if a suction head of 0.25m or more is required, then an electric fuel lift pump must be fitted (ask your dealer or Beta Marine).
3. It is very important that the excess fuel from the injectors is fed back to the fuel tank and not back to any point in the supply line. This will help prevent air getting into the system.
4. The fuel return (leak off) pipe must loop down to be level with the bottom of the tank before it enters the top of the tank – see drawing. This prevents fuel 'drain down'.
5. Fuel lines and hoses connecting the fuel tank to the engine, must be secured, separated and protected from any source of significant heat. The filling, storage, venting, fuel supply arrangements and installation must be designed and installed so as to minimise the risk of fire. When connecting the engine to the fuel supply and return lines, flexible fuel hoses must be used (next to the engine) and must meet the requirements detailed in standard ISO7840:1995/ A1:2000 and/or as required by your surveyor / authority.
6. Any fuel leaks in the system when static are likely to cause poor starting and erratic running and must be corrected immediately. These leaks will allow air to be sucked in when the engine is running.

▼ FUEL CONNECTIONS

Engine Connector


Fuel supply and leak-off connections are 8 mm conex with olives

Hose O.D.


8 mm O.D. piping for both, a flexible section is required

▼ CALORIFIER SYSTEM

26 Heat Exchanger Calorifier System




27 Keel Cooled Calorifier System




All Beta engines can be fitted with the calorifier connections to allow the coolant from the closed circuit cooling system to circulate through a calorifier tank, which in turn heats up domestic water. Calorifier connections on this range of engine are shown.

1. The big problem with a calorifier is to remove all the air from the system. If this is not achieved then they don't work!
2. Try and keep the supply and return pipes either horizontal or sloping down in a continuous fall towards the calorifier. This avoids air pockets being created.
3. Extra care must be taken when first connecting the calorifier circuit system to the engine as the coolant level in the heat exchanger may appear to be full but it soon disappears into the calorifier pipe work. Run the engine off load for 10 minutes then check the level as described in 'Filling The Fresh Water System'. Also check to see if the pipe going to the calorifier is getting warm. Top up the water level as required and run for another ten minutes then repeat.
4. If the water level is steady but no warm water is getting to the Calorifier then (with engine stopped) very carefully remove the pressure/filler cap using a large rag/cloth to protect you hand from scalding. Now very carefully open the Calorifier bleed valve (see manufacturers instructions) or if none is provided then very carefully loosen the jubilee clip securing the supply pipe to the Calorifier. Air should escape. Refasten securely when no further bubbles are seen.
5. If the calorifier tank is fitted above the heat exchanger / header tank then you will need to fit a remote header tank slightly above the calorifier tank.

28 Heat Exchanger Calorifier System



29 Heat Exchanger Calorifier System



⚠ CAUTION: **TO AVOID PERSONAL INJURY!**

Do not do this when the engine is hot as scalding hot water may be forced out of the pipe under pressure.

▼ CANAL BOATS WITH KEEL COOLERS

The majority of narrowboats on English canals have keel cooling, and this is our standard cooling arrangement for our 'Green Line' Narrowboats and 'Wide Beamers' (heat exchanger cooling is available as an option if required).

Narrowboats: These keel cooling 'skin' tanks are normally welded into the 'swim' of the narrowboat. They use the hulls' 8mm steel plate as one side of the keel cooling tank that transfers the engine heat into the canal water. The larger the engine / horse power the larger the 'skin' tank surface area that is required for keel cooling our engines. Keel cooling pipes under the hull of yachts or work boats, that achieve the same surface area can also be used.

Generally the keel cooling tank should have a surface area that is exposed to the canal or sea water of:

0.25 x the hp of the engine = the square feet of cooling tank area required (for steel hulls)

Engine (Narrowboats)	B14	B16	B20	B25	B30	B35	B38	B43	B50
Steel Tanks (Ft ²)	3.5	4.0	5.0	6.3	7.5	8.0	9.5	10.8	12.5
Steel Tanks (M ²)	0.33	0.38	0.46	0.59	0.70	0.82	0.88	1.00	1.16

Engine (Wide Beams)	B50	B60	B75	B90	B105	B110	B150
Steel Tanks (Ft ²)	12.5	15.5	18.8	22.5	25.0	27.5	37.5
Steel Tanks (M ²)	1.16	1.43	1.75	2.09	2.32	2.55	3.50

The ideal keel cooling tank should:

- Efficient keel cooling tanks are side mounted, as detailed in the illustration.
- The rubber hoses connecting the engine to the keel cooling tanks should be designed and manufactured as hot water heater hoses suitable for operation up to 100°C.
- The 'baffle' must be continuously welded to the outer skin and to one end as shown, and should be close to the inner skin.


Engine	B14 - B25	B30 - B60	B75 - B105	B150
Supply & Return Pipe	22mm	28mm	38mm	41mm
Baffle Gap Minimum	35mm	40mm	55mm	60mm
Baffle Gap Maximum	65mm	85mm	115mm	125mm

- The tank should be thin in section (C = 30mm to 40mm) as it is the heat transfer to the canal or river water that is important.
- The engine coolant for keel cooling (is the same 50:50 ratio of fresh water / antifreeze solution as heat exchanger cooling) and flows around the engine, then the keel cooling tanks, before returning to the engine.
- The keel cooling tank must have air bleed valves fitted on the top at both ends of the tank.
- The hot water feed enters at the top of the tank and the colder engine return comes out of the bottom.


Note: If your boat has a hydraulic drive, you will need to increase the surface area of the keel cooling tanks by approximately 30% percent. If you have any questions about keel cooling please refer to our design guidelines detailed on our website, or ask us.

30 Ideal Keel Cooling Tank

A x B = SURFACE AREA
(MUST BE BELOW WATER LEVEL)



31 Ideal Keel Cooling Tank



▼ ELECTRICAL INSTALLATIONS

All our engines are supplied with 12 volt electric starting as standard. We therefore supply the main components: starter motor, battery charging alternator, fuel control solenoid, glow plugs, engine temperature sensor, oil pressure sensor, control panel and a wiring loom connecting everything together. We do **not** supply as standard either the starter batteries or battery cables.

CONTROL PANELS

Heat Exchanger Cooled - We offer 5 control panels: the ABV is standard and the A, ABVW, B, C and D are optional. The engine harness is common to all. With our **Keel Cooled** Canal range the AB panel is standard or the 'C' panel is optional.

1. Control Panels must be fitted in a location where the helmsman can either see or hear the alarm system.
2. Our control panels are supplied as standard with a 3 metre multi-core cable for connection to the engine wiring loom. As an optional extra, Beta can provide various lengths of extension looms for runs of 5m or more, and this kit includes a start relay to overcome the voltage drop. (See drawing 300-58520).
3. For standard wiring diagrams see back of manual.
4. All electrical equipment must be protected from sea water. Sea water or rust in the starter motor

will invalidate the warranty. Care must be taken when pushing the two halves of the plug together to ensure that individual pins do not fall out. To prevent corrosion and assist in assembly we recommend that the plug is packed with petroleum jelly (Vaseline) and then carefully pushed together. The plastic boots should cover both halves and overlap. A cable tie is then put around to hold the two halves in position and help prevent any ingress of water.

5. The control panels must not be installed where sea water spray can get at them. We recommend that a suitable flap or cover is fitted.
6. All cables must be adequately clipped and protected from abrasion.
7. Electrical systems shall be designed and installed so as to ensure proper operation of the craft under normal conditions of use and shall be such as to minimise risk of fire and electric shock.
8. Attention shall be paid to the provision of overload and short circuit protection of all circuits, except engine starting circuits, supplied from batteries.
9. Ventilation must be provided to prevent the accumulation of gases, which might be emitted from batteries. Batteries shall be firmly secured and protected from ingress of water.

▼ BATTERY INSTALLATIONS - SOME CONSIDERATIONS

We would recommend keeping the electrical part of the engine installation as simple and as reliable as possible. We would suggest a dedicated battery for engine starting and if required, a domestic battery bank for other requirements.

Selecting the correct starter battery and battery cables is important as incorrect selection is a major cause of starting failure.

BATTERIES

1. **There are several different types of battery available to choose from:** a) Wet Lead Acid (invented in 1859); b) AGM (Absorbed Glass Mat - developed in 1972 as sealed Lead Acid); c) Gel (with a gelified electrolyte) developed in 1980; and d) Lithium-ion produced in 1991.

With boats there are two different requirements: a) A battery to drive the starter motor and b) A battery bank to power your domestic / auxiliary needs such as GPS, navigation equipment, lighting, music etc... **We recommend that you talk to a battery specialist for guidance.**

2. Climatic conditions will affect power output from batteries and at low temperatures the battery capacity will need to be increased as performance will decrease. (At minus 10 degrees centigrade battery output would be under 50 percent of normal output). This needs to be considered when first selecting your batteries.

3. All our engines are supplied with one battery charging alternator, sometimes two. Our electric starting circuit is nominal 12 volts and we fit as standard a 40 amp battery charging alternator up to Beta 25, and a 70 amp alternator from the Beta 30.
- 4). Battery size depends upon your requirements. For starter motor batteries the battery size should be based upon the starter motor requirements - table below, and never be of less capacity than the battery manufacturers recommendation. (You could oversize your battery by up to 20% to allow for gradual loss of capacity due to age and temperature etc.) - **If in doubt - ask.**

Typical starter motor ratings with Kubota engines

Suggested Minimum Battery Size					
Starter Capacity (kW)		Engines	Typical AH @ 20 hour rate	Typical AH @ 5 hour rate	Typical CCA (Cold Cranking Amps)
Less than 800cc	0.8 - 1.0	Beta 10 to 20	35 to 50 AH	28 to 40 AH	350 to 400
800 to 1,900cc	1.0 - 1.4	Beta 25 to 38	65 to 75 AH	53 to 62 AH	450 to 540
1,900 to 3,000cc	1.4 - 2.5	Beta 43 to 70	100 to 120 AH	80 to 96 AH	580 to 670
Over 3,000cc	2.5 - 3.0	Beta 75 to 105	150 to 180 AH	120 to 144 AH	1050 to 1200

5. If you require a domestic battery bank you will need to calculate your power requirements, and then multiply that by the number of hours you will need this power (before you are able to re-charge the batteries). To keep the installation simple and reliable we would recommend a second alternator for a domestic battery bank.

Generally it will take as long to recharge a battery as it does to discharge a battery. I know that this is an obvious statement but you can only recharge your batteries when the engines is running, so if you only use the engine for entering and leaving a marina you may need an alternative solution for recharging your batteries. Solar panels can be a good solution for keeping batteries 'topped up'.
6. Battery charging alternators must be suitable for the battery bank size. With 'Lead Acid' batteries it is recommended that if you wish to achieve a long battery life of 5 years and more - your alternator should be charging in Amperes at about 10 to 20 percent of the battery bank in 'Ampere Hours' (20 Hr rate).

Generally it is very easy to recharge to about 80 percent of battery capacity, but the last 20 percent is important if you wish to achieve a long battery life, and this can require an overnight charge. Battery life and recharging tends to be a compromise and it is generally recommended that the alternator output 'in amperes' is not more than 25 percent of the 'Ampere Hours' rating of the battery bank. The battery charging system must be a balanced solution; you must have enough battery capacity but bear in mind the recharge capability.
7. Batteries must be in good condition and must hold voltage. An idle standing battery would be expected to be at least 12.6 volts and we would like to see at least 12v on the starter motor terminals. (After a full charge the terminal voltage drops quickly to 13.2 V and then slowly to 12.6 Volts).
8. The maximum charging voltage for a Lead Acid battery is about 14.8 volts, above this voltage damage will occur. We would expect a maximum output voltage from our battery charging alternators of something like 14.8 volts at no load. At 50 percent load the voltage drops to 14.3 to 14.4 volts and at full output the voltage is 13.5.
9. Battery terminals and connections must always be kept clean, in good condition and tight. Faulty connections can lead to poor performance and even (in extreme conditions) explosion.

▼ BATTERY CABLES

1. Starter batteries should be as close to the engine as practically possible. The reason for this is to ensure that the maximum voltage from the battery is available to the starter motor. The longer the cable run - the more will be the voltage drop. This is due to the resistance of the cables.
 2. Generally speaking for smaller engines (say under 60hp) we recommend battery cables of 25mm² conductor cross sectional area with length up to 1.5m per cable. That equals a cable run of 3m total which would have a voltage drop in the region of 0.8v if the starter motor was using 160 amps when motoring. Battery cables that are too small will overheat and their insulation could catch fire.
 3. When the supply is switched on to the starter motor there will be a massive inrush of power in the region of 5 times the motoring current. The battery will be expected to supply this inrush and then recover sufficiently to give the motoring or 'rolling' current.
- If the correct battery is selected but the engine will not crank at sufficient speed after the inrush then (assuming battery cables are the correct size) the battery is either discharged or faulty.
4. If the voltage at the starter motor terminals after the inrush is not at least 10.5 volts it is likely that the motor will either crawl at insufficient speed or not turn at all. Battery cables could overheat.
 5. Battery cables are sized on the motoring or rolling current of the starter motor and the length of battery cable run. This length is the total distance of both the positive and negative cables added together. Under normal circumstances the voltage drop in the starter battery cable circuit should not exceed 0.8 volt and in any circuit should not exceed 1.2 volts.
 6. Please note that cranking time should be no longer than 10 seconds, with at least a 10 second rest between attempts.

25mm² Cable

Engine	Cranking Amps	Cable Volt drop*	Max length, both cables added together
Up to Beta 38	100	0.0017V	4.7m
Up to Beta 50	120	0.0017V	3.9m
Up to Beta 60	170	0.0017V	2.8m
Up to Beta 105	210 / 250	0.0017V	Not suitable
Beta 150	333	0.0017V	Not suitable

35mm² Cable

Engine	Cranking Amps	Cable Volt drop*	Max length, both cables added together
Up to Beta 38	100	0.0013V	6.2m
Up to Beta 50	120	0.0013V	5.2m
Up to Beta 60	170	0.0013V	3.6m
Up to Beta 105	210 / 250	0.0013V	2.5m
Beta 150	333	0.0013V	1.8m (70mm ² cable preferred)

70mm² Cable

Engine	Cranking Amps	Cable Volt drop*	Max length, both cables added together
Up to Beta 38	100	0.00063V	12.7m
Up to Beta 50	120	0.00063V	10.5m
Up to Beta 60	170	0.00063V	7.5m
Up to Beta 105	210 / 250	0.00063V	5.0m
Beta 150	333	0.00063V	3.8m

*Voltage drops for pvc insulated cables are ex table 9D1 of the IEE Wiring Regulations.

The above are based on a maximum conductor temperature of 70°C in an ambient temperature of 30°C.

Please note that it is not practical to use table 9D1 of the IEE Wiring Regulations for larger sizes. We are after all talking about short duration power flow not continuous ratings for the starter motor.

At the end of the day what matters is the voltage at the starter motor terminals before starting and whilst cranking, all without destroying the insulation on the cables.

▼ KEYSWITCH TERMINATIONS

The standard panel keyswitch can be used to tap off a switched positive ignition feed to power additional gauges. In this way these gauges will only be live whilst the engine is running, the engine is starting or the heaters are being used.

For silver keyswitches, the terminal to achieve this ignition switched positive is marked 'AC'.

For panels without any keyswitch, gauges can be driven from the 1mm² brown wire which terminates at 11 way connector terminal 4. This is a lower power switched positive, any additional power required from this connection must be feed through a relay, as noted below.

Note: these keyswitch terminals are rated at 10 amps maximum, since they are already utilised for panel and alternator feeds Beta Marine recommend any additional requirements from these terminals must be fed through a relay. This relay should then be connected to it's own fused positive supply directly from the engine battery.

Beta drawing 202-06421 illustrating the wiring of a typical electric fuel lift pump with ignition switched relay can be supplied upon request.

Section 2

▼ GUIDELINES FOR OPERATION OF ENGINE

IMPORTANT!


CHECKS PRIOR TO INITIAL USE

1. Generally, a new engine has the oil and anti-freeze removed after the works test. Fill the engine with the correct oil and antifreeze (see sections on Engine oil and Cooling). **Check gearbox oil level** - see gearbox 'Owners Hand Book'.
2. Ensure the engine is free to turn without obstructions.
3. Ensure battery is fully charged and connected with the battery isolator in the 'ON' position.
4. Ensure "Morse" speed and gearbox cables are fitted correctly and that cable travel lengths are correct.

Gear selection lever - all mechanical gearboxes: care must be taken to ensure that the remote control cable is adjusted so that the selector lever on the gearbox moves **full** travel and is brought "hard up" against its end stop in both directions.

Failure to achieve the correct adjustment will reduce efficiency of the clutch and may cause slippage at low revs. Warranty will not be accepted on gearboxes returned in the warranty period for failure due to incorrect adjustment.

5. Open the sea water cock - carefully checking there are no water leaks.
6. **Bleeding the fuel system for initial start up.**
 - a) The fuel system must have all the trapped air carefully 'bled' out; starting at the fuel tank and progressively working through to: the fuel/water trap, the fuel filter, to the fuel injection pump.
 - b) Open the fuel tank stop tap/valve and then bleed the fuel/water separator of air as shown in manufacturer's literature.
 - c) Fuel should now arrive at the fuel lift pump.
 - d) Open the fuel bleed screw on top of the fuel filter by 1 to 2 turns, see photo 33.



- e) Move the hand priming lever on fuel lift pump up and down until fuel with "no bubbles" comes out of the fuel filter bleed screw (photo 32). The hand priming lever normally has about 90° travel; **but the camshaft lobe may block this travel requiring you to rotate the engine 90° to obtain full travel.**
 - f) Shut/tighten the bleed screw.
 - g) Open the bleed screw on the fuel injection pump and again 'bleed' through to the injection pump. Continue to hand prime for 30 seconds to push fuel and any remaining air through the fuel pump. Clean all areas thoroughly of fuel with tissue paper.
7. Ensure engine is **out of gear** and set to 1/3 throttle - see "single lever control" instructions/manual.

8. Start engine (see normal starting). Note the engine may have to be turned over with the starter for a few seconds before it fires.

Do not run the starter for more than 20 seconds. If the engine has not started after 20 seconds there is probably still air in the fuel system; disengage the starter and continue to hand prime the engine with the fuel lift pump lever for a further 30 seconds, then repeat.

If engine does not start after 3 attempts then allow 5 minutes for the starter to cool down before repeating 6 (c) to 8.

Note: The starter motor windings can be burnt out with continuous cranking.

9. If the engine does not easily start at the first or second attempt, do not over crank the engine with the seawater inlet seacock turned 'on'. (This problem may have been caused by air in the fuel system, running out of fuel, or changing a fuel filter, etc).

You should close / shut off the seawater inlet seacock to stop seawater being pumped into the exhaust system and eventually filling up the combustion chamber, causing severe damage.

When you have resolved the problem, and the engine starts you must **immediately** open the seacock.

 **CAUTION:**

TO AVOID PERSONAL INJURY!

- Do not bleed a hot engine as this could cause fuel to spill onto a hot exhaust manifold creating a fire.
- Do not mix petrol / gasoline or alcohol with diesel fuel. This mixture can cause an explosion.
- Do not get diesel fuel or oil on the flexible mounts - they will deteriorate rapidly if soaked in these.
- Fuel must be removed from skin to prevent infection.

▼ NORMAL STARTING

BETA CONTROL PANELS - ABV, A, AB, B AND C DELUXE - WITH KEYSWITCH.



To operate the engine: with the engine out of gear, set speed control lever to $\frac{1}{3}$ throttle.

1. Turn key anti-clockwise to 'HEAT' position and hold for fifteen seconds maximum.
2. Turn key clockwise to 'RUN' position. At this stage the instrument panel should illuminate:
 - Red lamp for 'low oil pressure' should illuminate.
 - Red lamp for 'high engine temperature' should not illuminate (when engine is cold / cool / warm). This lamp will only ever illuminate if the engine is over temperature.
 - Red lamp for 'no starter battery charge' should illuminate.
 - Red lamp for 'no domestic battery charge'. **Only fitted with panels AB and C and will illuminate only if 2nd 'domestic' alternator is fitted.**
 - Green lamp for panel 'power on' should illuminate.
 - Buzzer should sound.
3. Turn to 'START' position and engine will motor, hold in position until engine fires (see initial start-up section for maximum time starter can be used).
4. Release key (when engine has started) to 'RUN' position.
 - All red warning lamps should extinguish and buzzer should stop sounding. The oil pressure lamp may take a few seconds to switch off and the charge fail lamp may remain on until engine rpm is increased to approximately 1,000 rpm if the engine was started on tickover.
 - Green lamp for 'panel power on' should still function.
 - If the 'charge fail' lamp remains on then "blip" the engine speed up to 2000 rev/min and it will go out (split charge relay drain).
5. Run the engine on fast tickover (1500 rpm) for it to warm-up.

▼ NORMAL STARTING

BETA CONTROL PANEL ABVW - KEYLESS (WITHOUT KEYSWITCH)



This panel controls the engine with three water resistant push buttons instead of a keyswitch, and is less prone to damage and corrosion from sea water spray.

To operate the engine: with the engine out of gear, set speed control lever to 1/3 throttle.

1. Press and hold 'HEAT' button for fifteen seconds maximum.

- Red lamp for 'no starter battery charge' should illuminate.
- Red lamp for 'high engine temperature' should not illuminate (when engine is cold / cool / warm). This lamp will only ever illuminate if the engine is over temperature.
- Red lamp for 'low oil pressure' should illuminate.
- Green lamp for panel 'power on' should illuminate.
- Buzzer should sound.

2. Press 'START' button and hold in position until engine fires (see initial start-up section for maximum time starter can be operated). Release button (when engine has started)

- All red warning lamps should extinguish and buzzer should stop sounding. The oil pressure lamp may take a few seconds to switch off and the charge fail lamp may remain on until engine rpm is increased to approximately 1,000rpm if the engine was started on tickover.
- Green lamp for 'panel power on' should still function.

3. To stop the engine press the 'STOP' push button, hold in until engine stops. This button also switches the power off to the gauges, engine and 'power on' lamp.

4. To re-start the engine, simply repeat steps from '1' above, there is no need to switch battery isolators off whilst remaining on board.

5. If leaving the boat, isolate start battery from engine and panel, to prevent accidental start up of engine and stop power leakage.

▼ STOPPING

Every propulsion engine is fitted with a stop solenoid. To stop the engine simply press stop push button, hold in until engine stops, then turn key from 'RUN' to 'OFF' position. Do not turn the key to the off position when the engine is running, this will not allow the alternator to charge the battery.

WARNING!

DO NOT leave the key in the 'OFF' position when engine is running. This will not allow the alternator to charge and will damage the alternator.


DO NOT leave the key in 'HEAT' position for more than 15 seconds - this will damage the heater / glow plugs and eventually lead to poor starting.

When leaving the boat for an extended period:

- Turn off sea-cock (heat exchanger cooled engines).
- Turn off battery isolator.

DO NOT depress the stop button for more than ten seconds as this will lead to overheating and failure of the solenoid.

These engines are equipped with a mechanical stop lever in the event of electrical system failure. This lever is located on the starboard side of the engine below the speed control lever. See illustration below. Move the stop lever aft to stop the engine then return it to the run position.



Section 3

▼ MAINTENANCE SCHEDULE

DAILY OR EVERY 8 HOURS RUNNING

- Check engine oil level.
- Check gearbox oil level.
- Check coolant level.
- Check battery fluid.
- Check drive belt tension
- Ensure raw water inlet strainer is clear.
- Check stern gland lubrication if used.
- Drain off any water in fuel/water separator.

AFTER THE FIRST 25 HOURS RUNNING

- Change gearbox lubricant (See separate gearbox manual).
- Check that all external nuts, bolts and fastenings are tight. See table for torque values. **Do NOT over tighten.** Special attention should be paid to the flexible mount lock nuts, these should be checked for tightness, starting with lower nut first in each case. If the lower nuts are found to be very loose, then the alignment of the shaft to the gearbox half coupling should be re-checked. Poor alignment due to loose flexible mount nuts will cause excessive vibration and knocking.
- Check the belt tension on any second alternators fitted and adjust, see page 11.
- Check ball joint nyloc nuts for tightness on both gearbox and speed control levers. Grease both fittings all over.

AFTER FIRST 50 HOURS

- Change engine lubricating oil.
- Change oil filter.
- Check for leaks on header tank tubestack. Tighten end cap bolt if required.
- Drain off any water in fuel/water separator.

AFTER 150 HOURS

- If shallow sump (option) is fitted, change engine lubricating oil and filter.

EVERY YEAR OR 250 HOURS IF SOONER

- Change engine lubricating oil (standard sump)
- Change lubricating oil filter
- Check air cleaner element
- Check sea water pump impeller and change if worn.
- Check wasting anode condition, replace when necessary. In some environments this may be six monthly or less.
- Remove heat exchanger tube stack, by undoing the bolt each end of the tube stack. Remove end cover, pull out tube stack and clean. Replace rubber 'O' rings and re-assemble. Top up with antifreeze. Immediately engine is started check for leaks.
- Spray the key switch with WD40 or equivalent to lubricate the barrel.
- Check that all external nuts, bolts and fastenings are tight. See table for torque values.
- Check ball joint nyloc nuts for tightness on both gearbox and speed control levers.

EVERY 750 HOURS (IN ADDITION TO 250 HOURS MAINTENANCE)

- Change air cleaner element.
- Change fuel filter.
- Change antifreeze.
- Change gearbox oil.
- Check electrical equipment, condition of hoses and belts, replace as necessary.

Maintenance Schedule

	Daily or every 8hrs running	After first 25hrs	After first 50hrs	Every 150hrs with shallow sump	Every Year or 250hrs if sooner	Every 750hrs
Check engine oil level	●	●	●	●	●	●
Check gearbox oil level	●	●	●	●	●	●
Check engine coolant level	●	●	●	●	●	●
Check battery fluid	●	●	●	●	●	●
Check drive belt tension	●	●	●	●	●	●
Ensure raw water inlet strainer is clear	●	●	●	●	●	●
Check stern gland lubrication	●	●	●	●	●	●
Drain off any water in fuel / water separator	●	●	●	●	●	●
Change gearbox oil		●	See separate gearbox manual			
Check all external nuts, bolts and fastenings are tight. Check belt tension. Check for leaks		●	●		●	●
Change engine oil			●	●	●	●
Change oil filter			●	●	●	●
Lubricate keyswitch on control panel with "vaseline" or WD40			●		●	●
Check coolant "sacrificial" zinc anode and replace if necessary - sometimes frequently			●		●	●
Check general condition			●		●	●
Remove heat exchanger tube stack and replace rubber O-rings					●	●
Check sea water pump impeller and change if worn					●	●
Check air cleaner element and change if required					●	●
Change air cleaner element						●
Change diesel fuel filter						●
Change gearbox oil						●
Drain and replace engine coolant / anti-freeze						●

▼ LUBRICATING OILS

Engine oil: Engine oil quality should have the minimum properties of the American Petroleum Institute “API” classification CF (CD and CE have been superseded by CF).

A good quality SAE 15W/40 mineral based multigrade oil as used in most car diesel engines will meet requirements.

An acceptable alternative are mineral based lubricating oils that are sometimes called semi-synthetic (or ‘synthetic blends’) and are blends of mineral oil with no more than 30% synthetic oil.

The following table gives grades of oil viscosity required for various ambient temperature ranges.

Ambient Temp.	Multi-Grade
-30°C to 0°C	SAE 10W/30
-15°C to +15°C	SAE 15W/40
0°C to +30°C	SAE 15W/40
25°C and above	SAE 15W/40

Note: Do not use lubricant additives, and we do not recommended totally synthetic oil.

▼ CHECKING THE ENGINE OIL LEVEL

For quantities of oil required please refer to our Operators Maintenance Manual. When checking the engine oil level, do so before starting, or more than five minutes after stopping.


1. To check the oil level, draw out the dipstick, wipe it clean, re-insert it, and draw it out again. Check to see that the oil level lies between the two notches.
2. If the level is too low, add new oil to the specified level.

When using an oil of a different make or viscosity from the previous one, drain out the old oil. **Never mix two different types of oil.**

Engine oil should be changed after first 50 hours running time and then every year or every 250 hours if sooner (Shallow sumps are every 150 hours).

Oil filter is a cartridge type mounted on the side of the engine and should be changed when you change the oil.

⚠ IMPORTANT! - Do not over fill!




▼ CHANGING THE ENGINE OIL

1. Run the engine for 10 minutes to warm up the oil, then stop it and open the oil filler cap.
2. Your engine is provided with a sump drain pump. Unscrew the end cap on the end of the pump spout, turn the tap to 'on'. Use the hand pump as shown to pump out the oil into a bucket. Turn the tap to off position and replace end cap. See photo 39.
3. Unscrew the oil filter and replace with a new one. See photo 40.


Note: It is best to have a plastic bag wrapped round the filter to catch any oil left in the system. (Always keep your bilges clean!) Before screwing in the new filter spread a thin film of oil round the rubber gasket to ensure a good seal and screw in - hand tight.

4. Fill the engine with new oil as described on the previous page and replace the oil filler cap.
5. Run the engine and check for oil leaks.



▼ CHECKING THE GEARBOX OIL LEVEL

1. The gearbox is fitted with a dipstick and oil filler plug, see photo 41.
2. Each engine is supplied with a gearbox 'operators manual' which specifies the type of lubricating oil to be used, the capacity and frequency of changing of the oil.
3. New engines are normally supplied with the gearbox topped up with lubricant but **check the level before starting the engine for the first time**.
4. The oil can be changed via the drain plug at the bottom of the box or sucked out with a hand pump via the filler plug.
5. A guide to the type of oil to be used is as follows:



Gearbox	Lubricant	Capacity (approx.)
TMC40	ATF	0.2 L
TMC60/A	ATF	0.8 L
TMC260	ATF	1.2 L
TM345/A	Oil	1.6 L
TM93/A	Oil	2.4 L
TM170/A	Oil	2.8 L

Gearbox	Lubricant	Capacity (approx.)
ZF 25/A	ATF	1.8 L
ZF 45/A	ATF	2.5 L
ZF 15 MIV	ATF	1.0 L
ZF 63 IV	ATF	4.0 L

Gearbox	Lubricant	Capacity (approx.)
PRM 80	ATF	0.6 L
PRM 120	ATF	0.8 L
PRM 150	Oil	1.4 L
PRM 260	Oil	1.5 L
PRM 500	Oil	2.5 L
PRM 750	Oil	2.5 to 3.5 L
PRM 1000	Oil	3.0 to 4.0 L

Note: ATF is Automatic Transmission Fluid.

For additional information please see manufacturers websites:

PRM: www.prm-marine.com

Technodrive: www.twindisc.com

ZF: www.zf.com

▼ CHANGING THE GEARBOX OIL

1. Run the gearbox for 10 minutes to warm up the oil.
2. Switch off the engine, remove the dipstick and begin to drain oil from the gearbox and cooling system. The drain plug is located on rear right hand side of the gearbox on most models.
3. Allow to drain, before refilling the gearbox with new oil as recommended.
4. Run the engine to allow oil to circulate, then stop and allow the oil to settle. Re-check the oil level and top up if necessary.
5. Ensure dipstick and cap are firmly secured and check for oil leaks, especially around the output shaft oil seal and gasket sealing surfaces.

▼ FUEL SYSTEM

⚠ IMPORTANT!

- Always fit a fuel/water separator in the fuel supply system. **Water in the fuel can seriously damage the injection system.**
- If a fuel supply shutoff valve is fitted do not use a taper tap, only use a ball valve tap. The ball valve type are more reliable and less likely to let air into the fuel system.
- Be sure to use a strainer when filling the fuel tank. Dirt or sand in the fuel may cause trouble in the fuel injection pump.
- Always use diesel fuel. **Do not use paraffin / kerosene**, as this has a low cetane rating and adversely affects the engine.
- Bio-diesel fuel can be added to the normal diesel fuel up to a maximum limit of 7% without affecting the warranty.
- Most diesel fuels now contain up to a maximum limit of 7% Biodiesel and this does not affect the engine warranty. The recent changes to fuel specifications allow the addition of FAME (fatty acid methyl ester) biodiesel EN14214:2009, to diesel fuel, but please be aware that biodiesel does allow bacteria to grow more easily in the fuel and this can clog your fuel tank, pipes and filters. If you experience an outbreak of bacterial growth you can either empty and clean out your fuel pipes and tank, or use biocide additives and filtering.

- Low sulphur diesel fuel - regulations changed recently reducing the sulphur content by 99%, in many countries. The European standard is EN590:2009, and in the USA ASTM D975-09. The engine is designed to run on low sulphur fuel, and this is now preferred.
- We know that some customers are using 100% Biodiesel fuel, if you use a higher percentage of Bio-diesel fuel you must fit an electric lift pump into the fuel supply line, and the fuel filter and oil filter must both be changed together when the oil filter is normally replaced.


⚠ IMPORTANT!

Beta Marine warranty will not cover fuel equipment when more than 7% Biodiesel is used.


- Be careful not to let the fuel tank become empty, or air can enter the fuel system, necessitating bleeding before next engine start.
- The fuel lift pump will only lift fuel through 0.25m. If this is insufficient then an electric fuel lift pump must be fitted. Drawing 202-06421, illustrating recommended wiring for this pump can be supplied upon request.

▼ FUEL FILTER REPLACEMENT

1. The fuel filter is a spin on type. Remove by turning anti-clockwise when viewed from below.
2. Replace the fuel filter cartridge every 750 hours or every 2 years. See photo 42.
3. Apply fuel oil thinly over the gasket and tighten into position - hand tight.
4. Bleed as detailed - see 'initial start up'.
5. Check for leaks.
6. Do not get fuel on the flexible mounts, this will degrade and damage the rubber.



▼ HEAT EXCHANGER COOLING



All diesel engines require a cooling system. Generally all modern seagoing boats with wooden or GRP (Glass Reinforced Polyester) hulls normally have a Heat Exchanger 'Fresh Water' cooling system.

Heat Exchanger cooling takes in sea water through the bottom of the hull via a seacock usually with a strainer, to the seawater pump mounted on the engine. The seawater is pumped through piping to the heat exchanger where it passes through the cupronickel 'tubestack'; first through the bottom pipes, then back through the top pipes and then out into the exhaust injection bend. From the

43 Heat Exchanger Cooled Engines

injection bend the seawater falls into the waterlock and is then blown with the exhaust through a 'gooseneck' and out of the stern of the boat. The engine cooling has a closed circuit that uses a coolant solution of 50% 'Fresh Water' and 50% antifreeze. This coolant circulates round the engine collecting heat and transfers the heat to the seawater in the heat exchanger as it circulates around the outside of the cupronickel 'tubestack' pipes.

A typical heat exchanger cooling system is shown on the inside front cover, and detail drawings are included in the following pages to ensure a reliable installation.

▼ ENGINE 'FRESH WATER' COOLANT

The coolant solution must be a mixture of fresh water and anti-freeze (Ethylene Glycol based conforming to BS6580:1992) with the antifreeze being a 50% solution (this also applies to warm and tropical climates). This not only stops 'freezing up' in winter, but it also prevents overheating and corrosion. The warranty is invalid if the correct percentage / ratio is not used.

The anti-freeze in the fresh water system enables the boiling point of water to rise to 124°C with a 13 psi pressure cap fitted. The water temperature alarm switch will however be activated at 95°C to 100°C. If no anti-freeze or a very weak solution is used, then the water temperature switch may not be activated before coolant is lost.

▼ RAW WATER COOLING - KEEL COOLING


Older marine engine designs have used 'Raw Water' cooling. This is when the seawater circulates directly through the engine cooling circuit and will over time corrode the inside of the engine. Seawater is very corrosive and the salts can also cause scale build-up in narrow coolant passageways. Beta Marine do not offer 'Raw Water' cooling.

Keel Cooling is often used on steel work boats, fishing boats and inland waterway boats where a grid cooler or heat transfer tank are built into the hull to give a closed circuit system. In these applications no seawater pump is used and the engine circulating pump pushed the water / antifreeze solution round the closed system.


▼ FILLING THE FRESH WATER SYSTEM

New engines are supplied with the fresh water 'coolant' drained off. The following instructions must be followed to fill the system.

- a) Pour into a clean bucket a mixture of both fresh water and anti-freeze; with an anti-freeze ratio of 50% (see next page). For the required volume see technical specification page 4.
- b) Check that the coolant drain tap or plug is turned off. See photo 44.



- c) Fill engine with freshwater / anti-freeze solution through the top of the heat exchanger or header tank with the filler cap removed. See photo 45.



- d) Fill header tank to the top of the filler neck and replace cap. Press down firmly on filler cap and hand tighten in a clockwise direction.

Note: For keel cooled engines a large quantity of coolant (anti-freeze solution) is required depending upon the size of the keel cooling system (refer to builder's instructions).

- e) Run the engine for 5 minutes on no load (out of gear) and check coolant level, this will help remove air from the system. Top up as necessary.

- f) Check system for leaks.

Note: For keel cooled engines it is very important to bleed all of the air out of the complete cooling system before the engine is run on load (check with builder's instructions).

- g) If a calorifier is fitted care must be taken to see that this is also full of coolant and all the air is expelled. (See calorifier fitting notes under Section 1).
- h) Run the engine on one third load for 15 minutes, preferably with the boat tied up. As the system warms up coolant may be expelled from the overflow pipe into the bilge. Stop the engine and allow the engine to cool down before removing the pressure cap and top up the coolant to 25 mm / 1" below the filler neck.

CAUTION:

TO AVOID PERSONAL INJURY!

Removal of the pressure cap when the engine is hot can cause severe injury from scalding hot water under pressure. Always allow the engine to cool and then use a large cloth when turning the cap anti-clockwise to the stop. This allows the pressure to be released. Press firmly down on the cap and continue to turn anticlockwise to release the cap.

- i) Repeat (h) if coolant level is more than 1 inch below the base of the filler neck when the engine has cooled down.
- j) Run engine on $\frac{2}{3}$ full load for 20 minutes, check for leaks and repeat (i).
- k) Anti-freeze solutions should be drained off every 2 years and replaced with a new solution.

Note: When draining fresh water system, ensure the engine has cooled sufficiently to prevent scalding from hot pressurised water. Prior to draining a cold engine, remove the filler cap from the header tank and then open the water drain tap. This allows the water to drain freely from the system.

▼ SEA WATER PUMP AND COOLING SYSTEM

IMPORTANT!


Before working on the sea water system ensure that the **sea cock is in the off position!**

1. It is very important that the correct sea water flow is maintained to cool the closed circuit system of the engine. The key component in this system is the sea water pump impeller. This should be checked every year by removing the circular plate. See photo 46.
2. Withdraw the rubber impeller from its drive shaft as shown. See photo 47. Pliers may be required.

3. Check impeller for cracks in the rubber, excessive wear or lost vanes. Replace with a new impeller as necessary. A drop of washing up liquid on the impeller will help to push it into position.


Note: If any pieces of rubber impeller are missing then they must be found as they are most likely to be trapped in the entrance to the heat exchanger cooling stack. See 'Cleaning Tube Stack'.

4. Re-assemble using new 'O' rings. Do not over tighten end cap bolts and **make sure the tube stack is the right way round** for end cap location.
5. Re-fill engine with coolant (water/anti-freeze solution) and run engine up to temperature to check for leaks.



▼ HEAT EXCHANGER TUBE STACK AND 'WASTING ZINC ANODE'

1. The wasting zinc anode should be checked regularly at least every six months and replaced every year or sooner, as necessary. The anode is attached to the bolt inserted in the end cap of the heat exchanger. See photo 48. On most engines this is on the aft end.
2. Unscrew the bolt and replace the complete unit with a new one.
3. It is possible for fine sea weed and other debris to get past the inlet filter and into the tube stack. This should be removed and cleaned. See photo 49.
4. Drain off coolant into a bucket.
5. Unscrew the 6 end cap retaining bolts using a 5 mm Hex key (3 each end of the heat exchanger). Remove the 'O' rings and slide out tube stack. Carefully clean tube stack and end caps.
6. Re-assemble using new 'O' rings. The tube stack can be fitted either way around but must be aligned correctly with the horizontal line and rubber seal between the alignment marks at the exhaust end of the heat exchanger. (This ensures correct coolant flow in the heat exchanger) Do not over tighten end cap bolts.
7. Re-fill engine with coolant (water / anti-freeze solution) and run engine up to temperature to check for leaks.



▼ BELT TENSION

WARNING!

Belt tension must only be checked with the engine switched off.



40 AMP ALTERNATOR (HEAT EXCHANGER COOLED)

These engines are fitted as standard with a single belt that drives both the battery charging alternator and the fresh water / engine coolant circulating pump.

1. The belt tension is adjusted by swinging the alternator outboard as it pivots on its support bolts. See photo 51.
2. With the engine stopped, loosen the support bolts and the link adjusting bolt.
3. Push alternator outboard by hand to tension the belt, then tighten link bolt.
4. Check that the depression of the belt (at position shown) is approximately $\frac{1}{2}$ " or 12 mm when pushed down firmly by thumb. Tighten support bolts. See photo 52.
5. Belt tension should be regularly checked especially during the first 20 hours of running in a new belt, as stretching occurs.


LARGER ALTERNATOR (OPTION)

The same method applies as outlined above with the 'polyvee' flat belt, but final tensioning must be by hand only. Over tensioning will cause premature failure of components.



▼ AIR FILTER

These engines are fitted with an air intake filter which should be checked every season and changed every 2 years or sooner if badly clogged. If badly clogged check more often.



▼ ELECTRICAL MAINTENANCE

WARNING!

UNDER NO CIRCUMSTANCES SHOULD THE BATTERY BE DISCONNECTED OR SWITCHED OFF WHEN THE ENGINE IS RUNNING. THIS WILL SERIOUSLY DAMAGE THE ALTERNATOR.

▼ PANELS AND WIRING

SEE INSTALLATION NOTES, PAGE 30.

▼ GENERAL MAINTENANCE

1. The control panel must be protected from rain and sea water, see installation. Sea water entering the key switch will eventually cause corrosion and could result in the starter motor being permanently energised and burning out. Spray key switch every month with WD40 or equivalent; or apply 'vaseline'.
2. Check batteries for acid level and top up if required. For low maintenance and 'gel' batteries see manufacturers instructions.
3. Loose spade terminal connections are the most common cause for electrical faults - check on a regular bases (see maintenance instructions).

▼ WINTERISING AND LAYING UP

- a) The engine lubricating oil and lubricating oil filter should be changed at the end of the season rather than in the spring. See section 2.
- b) The closed circuit cooling system must contain an anti-freeze coolant solution. The coolant solution is a mixture of fresh water and anti-freeze (Ethylene Glycol based conforming to BS6580:1992) with the anti-freeze being a 50% solution (this also applies to warm and tropical climates). The warranty is invalid if the correct percentage/ratio is not used.
- c) For cold climates where the air or water temperatures can fall below 3°C, the sea water circuit must be protected in addition to the fresh water system. This is best achieved as follows:
 - Close the inlet seacock to the engine (engine stopped).
 - Disconnect the sea water inlet pipe and dip it into a small bucket containing 50/50 anti-freeze solution.
- Start the engine (out of gear) and run for 5 to 10 seconds until the anti-freeze is used up and can be seen coming out of the exhaust outlet.
- Shut engine off and reconnect the inlet pipe to the seacock. The sea water or raw water circuit is now protected by anti-freeze.
- d) Ensure instrument panel is well protected and give the key switch a spray of WD40 / Petroleum Jelly or equivalent.
- e) With the engine stopped, disconnect the battery (always disconnect the negative cable first and re-connect the negative cable last) and take it ashore for trickle charging and top up as necessary. If AC power is available then this can be done on the boat.
- f) Fuel tanks should be kept full during the lay up period to eliminate water condensation in the tank. Water entering the fuel injection system can cause considerable damage.

▼ LAYING UP ASHORE


- a) Change the engine oil before the boat is taken out of the water. Remember that warm engine oil is much easier to pump than cold!
- b) Cooling system - As above in 'Winterising and Laying up' paragraphs (b) to (f) should be followed.
- c) If the engine is to be laid up for more than 6 months then remove the sea water pump impeller.
- d) If the engine will not be used or run for periods longer than 6 months we recommend that the engine is 'inhibited' - this involves running the engine for about 5 minutes to:
 - Replace all the diesel fuel in the fuel system and injection pump by running the engine with 'calibration fluid' (fuel pump test oil ISO 4113).
 - Allow 'Ensis' to circulate around the lubricating oil system by draining out the standard lubricating oil and replacing it with a rust preventative oil such as 'Ensis' or similar.

Trouble Shooting

Beta diesels are very reliable if installed and serviced correctly, but problems can occur and the following list gives the most common ones and their solution.

Problem: Engine does not start but starter motor turns over OK	
Possible Cause	Solution
No fuel:	Turn fuel cock on and fill tank.
Air in fuel system:	Vent air (see initial start-up)
Water in fuel:	Change fuel filter, check fuel / water separator and bleed system.
Blocked fuel pipe:	Clean out and bleed system.
Fuel filter clogged:	Change filter and bleed system.
Fuel lift pump blocked:	Remove and replace.
Blocked injector:	Remove and clean.
Fuel return not fed back to the tank:	Re-route fuel return pipe.
Heater plugs not working:	Check wiring to the plugs, and replace plugs if they are burnt out.
Stop solenoid stuck in off position:	Check solenoid is free to return to run position.

Problem: Starter motor will not turn or turns over very slowly	
Possible Cause	Solution
Battery discharged:	Charge battery or replace. Check alternator belt tension.
Starter motor flooded with sea water:	Remove and clean, or replace.
Wiring disconnected or loose:	Check circuit for loose connections.
Water in cylinders:	Incorrect installation. This is serious - check engine oil for signs of water (creamy-coloured oil). Ring your dealer.
Engine harness fuse blown:	Replace fuse located by starter motor (or above flywheel housing) and check for wiring faults.



Fuse.

Note: For convenience, some engines are supplied with a spare fuse and holder attached to the main engine fuse holder.

Problem: Low power output

Possible Cause	Solution
Propeller is too big:	Change or depitch.
Check gearbox reduction ratio relative to propeller size:	Change.
Blocked fuel filter:	Replace.
Blocked air filter:	Replace.
Air in fuel system:	Check system and bleed
Governor spring incorrectly mounted:	Dealer to adjust.
Single lever control not operating correctly:	Disconnect speed control cable and move the lever by hand. Adjust cable.
The electrical load is too large on start up:	Disconnect or reduce the load.

Problem: Erratic running / hunting

Possible Cause	Solution
Air in fuel supply:	Check supply system for leaks and fix.
Fuel lift pump faulty:	Replace.
Clogged fuel filter:	Replace.
Fuel return not fed back to the fuel tank, or blocked pipe:	Re-route pipe or clean.
Air filter blocked:	Replace.
Worn or blocked injector:	Service injectors.
Engine rpm in gear is too low, this must be 850 min:	Increase engine tick over speed.
Faulty stop solenoid:	Disconnect wiring to solenoid. If running improves check for a wiring fault.
Broken fuel injection pump spring:	Replace, this is usually caused by water in the engine oil/fuel
Fuel suction head is too much:	Fit electric fuel lift pump.

Problem: Hunting at idle

Possible Cause	Solution
Idle adjustment screw may need adjusting:	Speak to Beta Marine for advice with idle adjustment - discuss problem.

Problem: Hunting at higher speeds

Possible Cause	Solution
Fuel supply problem:	Change fuel filters and check fuel supply.

Problem: White or blue exhaust gas

Possible Cause	Solution
Engine oil level too high:	Reduce the level.
Blocked injector:	Service injectors.
Piston ring and bore worn or con rod bent due to water ingress, giving a low compression:	Get compression checked by your dealer or Kubota service agent. He will advise action to be taken.
Check that the breather pipe is clear and not obstructed:	Remove and clean out

Problem: Black exhaust gas

Possible Cause	Solution
Blocked air filter element:	Inspect and replace.
Over pitched propeller - engine will not reach its full rpm:	Get the propeller re-pitched if necessary.
Accumulated debris on hull:	Inspect and clean if required.

Problem: Low oil pressure warning light on when underway

Possible Cause	Solution
Oil frothing due to high installation angle or too high oil level:	Refer to Beta Marine for advice

Problem: Low oil pressure warning light on when engine speed reduced to tick over

Possible Cause	Solution
Faulty switch sender:	Replace.
Engine running too hot:	Check cooling water flow (see section 2 Cooling).
Oil relief valve stuck partially open with dirt:	Remove and clean.
Blocked oil filter:	Change.
Wiring fault:	Check circuit.
Insufficient oil:	Top up and check for leaks.

Problem: High oil consumption

Possible Cause	Solution
Oil leaks:	Check for leaks.
Piston rings worn:	Overhaul required.
Valve stem and guide worn:	Overhaul required.
Piston rings gap facing the same direction:	Shift ring gap position. Service Agent to check.

Problem: Water in lubricating oil - general

Possible Cause	Solution
Core plug pushed out due to frozen block:	Service Agent to check and replace.
Water pump seal damaged:	Service Agent to check and replace.

Problem: Water in lubricating oil - heat exchanger cooled

Possible Cause	Solution
Oil goes "milky" due to seawater entering exhaust manifold:	Check installation - has anti-syphon valve been fitted? Change engine oil and run engine for 10 minutes each time to eliminate any water. Get fuel injection pump and compression checked by Service Agent.

Problem: Water in lubricating oil - keel cooled

Possible Cause	Solution
Oil goes "milky" due to water entering exhaust manifold and then into the sump:	Check installation - has dry exhaust system been fitted correctly, and ensuring rain water cannot enter the exhaust port and run back? (See Dry Exhaust System). Change engine oil and run engine for 10 minutes each time to eliminate any water. Get injection pump checked by Service Agent.

Problem: Engine overheats - general

Possible Cause	Solution
Low raw water flow:	See below.
Check coolant level:	Top up.
Pressure cap loose:	Tighten correctly or replace.
Switch sender faulty:	Replace.
Insufficient restrictions in pipe to calorifier:	Clamp off pipe to confirm.
High exhaust back pressure:	Must not exceed the information given in 'exhaust back pressure' in the installation section.
Keel cooler insufficient size:	Contact boat builder

Problem: Engine overheats - Heat exchanger only

The most common cause of overheating is insufficient seawater flow due to a blocked intake (weed or a plastic bag!). If this happens then clear the blockage. If the problem is not cured then check the system for sea water flow which should be 12 litres / minute minimum at 1,500 rpm as follows:

- With the boat tied up and out of gear run the engine up to 1500 rpm. Hold a plastic bucket over the exhaust outlet for 10 seconds and measure the amount of water collected*. Multiply this value by 6 to give the flow in litres / minute. Repeat twice and take an average. If the flow rate is noticeably less than the 12 litre per minute minimum at 1,500 rpm, then:
 - Check impeller in sea water pump - if worn replace.
 - If impeller has a vane missing then this will be lodged either in the pipe to the heat exchanger or in the end of the exchanger. This must be removed.
 - Check flow again as in (a).

***Note:** This operation must only be done in safe conditions, in port and with two assistants. Working from a rubber dinghy is best. The person holding the bucket should take precautions against breathing in the exhaust gasses.

Problem: Engine overheats - Keel cooling only

Sometimes overheating is caused by:

- (a) Not fully venting the engine cooling system of air. It is necessary to remove all air from the cooling system - including the "skin" tanks and (if fitted) the Calorifier and associated piping.
- (b) Incorrectly sized "skin" tanks that have been sized for 'usual' canal use (rather than maximum engine output that can sometimes be required) on fast flowing rivers. An additional "skin" tank may need to be fitted; please refer to our website: Inland waterways - Guidelines: keel cooling tank sizes.

Problem: Battery quickly discharges

Possible Cause	Solution
High load and insufficient running:	Reduce load or increase charging time. Large domestic battery banks subject to high electrical loads will take a considerable time to recharge from a single alternator.
Low electrolyte level:	Top up.
Fan belt slipping - black dust in engine compartment, engine compartment temperature too high:	Adjust tension / replace belt with a high temperature type and / or improve engine compartment ventilation.
Alternator defective:	Check with Agent.
Battery defective:	Replace.
Poor wiring connection:	Check wiring system.

Problem: Morse control cable will not fit

Possible Cause	Solution
Incorrect fitting:	Cables are being fitted the wrong way around, switch over and fit the opposite way.

Problem: Panel rev counter not working (when fitted)

Possible Cause	Solution
No W connection to alternator:	Check output from 'W' connection. Should be about 9V AC
Wiring fault:	Check circuit

Problem: Transmission noise

Possible Cause	Solution
Check gearbox oil level:	Top up.
"Singing" propeller:	Check with propeller supplier about 'harmonics'.
Drive plate rattle at tickover:	Check engine rpm (must be 850rpm min. in gear).
Worn drive plate:	Change.
Propeller shaft hitting the Gearbox half coupling:	Move shaft back to give 5mm - 10mm clearance (Type 12/16 couplings only).
Propeller torsionals causing gears to rattle at low rpm:	Fit a torsional flexible coupling such as Centaflex type 16 or equivalent.

Problem: Vibrations

Possible Cause	Solution
Poor alignment to shaft:	The alignment must be accurate even if a flexible coupling is used (see section 1, Alignment).
Flexible mounts not adjusted correctly to take even weight:	Check relative compression of each mount.
Flexible mount rubber perished:	Replace. (Diesel or oil will eventually perish most rubbers.)
Loose securing nut on flexible mount:	Check alignment and then tighten the nuts.
Insufficient clearance between the propeller tip and the bottom of the boat:	There must be at least 10% of the propeller diameter as tip clearance between the propeller and the bottom of the boat. Reduce propeller diameter / increase pitch.
Loose zinc anode on the shaft:	Tighten or replace.
Worn cutless bearing or shaft:	Replace.
Weak engine support / bearers:	Check for cracked or broken feet.

Problem: Knocking noise

Possible Cause	Solution
Propshaft touching gearbox output coupling through split boss or Type 16 coupling:	Adjust, giving correct clearance give 5mm - 10mm between gearbox and propeller shaft
Flexible mount stud touching engine bed:	Adjust stud to clear
Drive plate broken:	Replace / repair
Engine touching engine bed:	Re-align engine / modify bed
Injectors blocked through excess carbon caused by water in the fuel:	Remove and check injector nozzles, replace if required.

▼ ELECTRICAL FAULT FINDING (ENGINES AFTER JULY 2005 ONLY)

The following chart is compiled to aid diagnosis of electrical faults, based on the Beta 10 - 90hp range of engines. If your engine was built before July 2005, contact Beta Marine for the relevant electrical trouble shooting guide.

Note: our standard control panels are for earth return installations only (where battery negative cable is connected directly to engine ground). For insulated earth (where battery negative cable is isolated from engine ground) different harnesses, alternators, switches for oil pressure and engine temperature are fitted.


Standard sea specification engines (heat exchanger cooled) are supplied with a single alternator, mounted port side, supplying power to starter battery and control panel. Standard canal specification engines (keel cooled) are supplied with twin alternators:

- 1st alternator, mounted port side, supplying power to starter battery and control panel
- 2nd alternator, the standard mounting position for this is above the engine on the starboard side (or below 1st alternator on 75 and 90hp), supplying power to the domestic battery system.

Both of these alternators work independently, if the domestic battery system is disconnected, the engine will still run correctly but:

- Domestic charge warning lamp will not function
- Warning buzzer will remain on at all times

Note: The two way plug on panel loom will only have a corresponding socket to connect into from the engine if a 2nd alternator is fitted which requires this connection. Engines with only one alternator do not utilise this connection.



STANDARD KEYSWITCH CONTROL PANELS ARE SUPPLIED WITH FOUR OR FIVE LAMPS.

Four lamp panels: A, ABV, B these panels utilise bulbs inside sealed lamp holders.

Five lamp panels: AB and C; these panels also utilise bulbs inside sealed lamp holders, having an additional lamp for 'domestic battery charge'.



Turn on battery isolating switch. With keyswitch* in run position and engine off:



Red lamp for 'low oil pressure' should function.



Red lamp for 'high engine temperature' should not function (when engine is cold/cool/warm).

This lamp will only ever function if the engine is over temperature.



Red lamp for 'no starter battery charge' should function.



Red lamp for 'no domestic battery charge' should function (**Note:** this will only function if a second alternator is fitted to the engine and connected to a charged battery).




Green lamp for 'panel power on' should function. Buzzer should sound.

▼ ELECTRICAL FAULT FINDING (ENGINES AFTER JULY 2005 ONLY)

ABVW - KEYLESS FOUR LAMP PANEL (WITHOUT KEYSWITCH)

This panel controls the engine with three water resistant push buttons instead of a keyswitch, and is less prone to damage and corrosion from sea water spray. This panel utilises bulbs inside sealed lamp holders



Turn on battery isolating switch.

1. Press and hold 'HEAT' button for ten seconds maximum.



Red lamp for 'low oil pressure' should function.



Red lamp for 'high engine temperature' should not function (when engine is cold/cool/warm). This lamp will only ever function if the engine is over temperature.



Red lamp for 'no starter battery charge' should function.



Green lamp for 'panel power on' should function. Buzzer should sound.

2. Press 'START' button and hold in position until engine fires (see initial start-up section for maximum time starter can be operated). Release button (when engine has started).



All red warning lamps should extinguish and buzzer should stop sounding. The oil pressure lamp may take a few seconds to switch off and the charge fail lamp may remain on until engine rpm is increased to approximately 1,000rpm if the engine was started at tickover.



Green lamp for 'panel power on' should still function.

3. To stop the engine press the 'STOP' push button, hold in until engine stops. This button also switches the power off to the gauges, engine and power on lamp. Before investigating any specific electrical problem, always check:

- Connection between panel harness and panel loom. It must be clean, dry and secured with a cable tie.
- Check the start battery is connected to the correct terminal on the starter motor.
- Check the domestic battery is switched on and connected to the correct terminals for the 2nd alternator.
- Battery connections, inspecting condition of cables from battery to engine. If in doubt measure the voltage at the engine.
- If alternator charge problem, measure battery voltage with engine off and again with engine running, if there is an increase alternator is functioning correctly, if not refer to check list.

▼ ELECTRICAL FAULT FINDING - ALL LAMP PANELS

Problem	Possible Cause and Solution
No warning lamps or buzzer functioning, engine will not start or stop	<ul style="list-style-type: none"> • Battery isolation switch in off position - switch on • Starter battery discharged - charge • Engine fuse blown - check fuse (above starter motor or flywheel housing) and replace if necessary • Check for wiring faults
Non function of warning lamp. The water temperature lamp will not function unless engine is overheating or there is a wiring fault	<ul style="list-style-type: none"> • Disconnect switch wire to non-functioning lamp: green/blue –water temperature, white/brown –oil pressure, brown/yellow –alternator charge. Reconnect wire temporarily to another warning lamp that is functioning; if wire switches lamp on replace faulty lamp • Disconnect positive feed to non-functioning lamp. Reconnect temporarily with wire from another warning lamp that is functioning, if wire switches lamp on rewire with new connection • If none of the above, check continuity of connections from panel to engine
Water temperature warning lamp on when engine is not over temperature (Not B or C deluxe panel see table on following page)	<p>If engine is cold:</p> <ul style="list-style-type: none"> • Faulty wiring, check connection and continuity (small green/blue) from switch to panel lamp. Ensure this connection is not shorting to earth (ground) • Faulty temperature switch - if lamp switches off on removal of connection to switch unit, replace <p>If engine is warm:</p> <ul style="list-style-type: none"> • Switch wire connected to large sender terminal of switch/sender unit. Remove and refit to smaller (switch) terminal
Buzzer not functioning. The buzzer will not sound for green 'power on' lamp	<ul style="list-style-type: none"> • If lamp is functioning but buzzer not sounding, check connection and continuity from illuminated warning lamp (red not green) to buzzer board • Faulty warning panel buzzer board - replace
Starter battery charge lamp not functioning	<p>If tacho not functioning:</p> <ul style="list-style-type: none"> • Alternator not connected properly, check continuity of small brown wire from rear of alternator to 'AC' position on keyswitch • Alternator connected properly, faulty alternator - replace <p>If tacho functioning correctly:</p> <ul style="list-style-type: none"> • Check continuity of small brown/yellow wire from rear of alternator to no charge warning lamp on rear of panel • If alternator connected properly, faulty panel warning lamp - replace
If tacho not functioning	<ul style="list-style-type: none"> • Check connections on rear of tacho, especially black/blue wire, terminal '4' • Check connection of black/blue wire on rear of 1st alternator (W connection, usually a bullet on flying lead, or lowest connection on alternators with 3 pin coupler) • Check continuity of black/blue wire from alternator to tacho • Measure voltage from alternator W connection to earth (ground), should be approx. 7.5 - 9.0 volts AC
Domestic charge lamp not functioning, buzzer remains on with engine running	<ul style="list-style-type: none"> • Domestic battery not connected • Domestic battery not connected correctly: B+ to domestic isolation block on starboard rail (port on 75 - 95hp) B- to engine earth (ground) • Domestic battery flat • Panel relay faulty / incorrectly wired: Check voltage at relay terminal 86, white wire is positive feed for warning lamp from AC position of keyswitch
Domestic charge lamp not functioning, buzzer switching off with engine running. This lamp will only function if a second alternator is fitted to the engine	<ul style="list-style-type: none"> • No second alternator fitted to engine, domestic lamp not used • D+ (charge indication) lamp connection at rear of alternator not connected • Two way plug and socket disconnected between engine harness and panel loom

▼ ELECTRICAL FAULT FINDING - C DELUXE AND B PANELS

In addition to the fault finding detailed on the previous table, the following is specific for the deluxe panel (Also applicable for the B panel with Murphy water temperature gauge)

Problem	Possible Cause and Solution
Oil pressure warning lamp not functioning, oil pressure gauge showing maximum deflection. Engine off and keyswitch in run position	<ul style="list-style-type: none"> Faulty wiring - check wire connection and continuity (small white/brown) from sender to panel lamp. Ensure this connection is not shorting to earth (ground)
Oil pressure gauge showing no movement - even when engine is started. Warning lamp functioning correctly	<ul style="list-style-type: none"> Faulty wiring - check oil pressure sender wire (small white/brown) is connected
Oil pressure showing no movement, warning lamp not functioning correctly	<ul style="list-style-type: none"> Check connection to oil pressure gauge, if plug is not connected to socket on rear of gauge, reconnect If all connections are correctly made, possible faulty sender unit - check resistance to earth, approx. 50 Ω. Replace if no reading or short-circuited If adjusted correctly and buzzer still sounding, possible faulty switch gauge unit - replace
Oil pressure showing normal operating pressure (0.75 - 5 bar). Buzzer sounding and lamp illuminated.	<p>Engine warm:</p> <ul style="list-style-type: none"> Incorrectly calibrated switching point for warning lamp, adjust on rear of gauge to 0.5 bar (minimum adjustment on gauge) If adjusted correctly and buzzer still sounding, faulty switch gauge unit - replace
Water temperature gauge showing 120°C / 250°F. This also applies to the B Panel with Murphy gauge	<p>Engine cold / cool:</p> <ul style="list-style-type: none"> Faulty wiring, check water temperature sender wire is not shorting to earth (ground) Faulty sender unit, - check resistance to earth, approx. 3.5k Ω (cold) – 0.5k Ω (warm). Replace if notably less
Water temperature gauge showing normal operating temperature (85°C). Buzzer sounding and lamp illuminated. This also applies to the B Panel with Murphy gauge	<p>Engine warm:</p> <ul style="list-style-type: none"> Incorrectly calibrated switching point for warning lamp adjust on rear of gauge to 100°C / 210°F. If adjusted correctly and buzzer still sounding, faulty switch gauge unit - replace
Water temperature gauge showing no movement, lamp not illuminated, engine warm. This also applies to the B Panel with Murphy gauge	<ul style="list-style-type: none"> Check connection to sender, if disconnected gauge will not function Check connection to temperature gauge, if plug is not connected to socket on rear of gauge reconnect. If all connections are correctly made, faulty sender unit - check resistance to earth, approx. 3.5k Ω (cold) - 0.5k Ω (warm). Replace if no reading

▼ ELECTRICAL FAULT FINDING - NON-BETA PANEL

Engines can be supplied wired up to suit VDO switch senders, usually fitted to a non-Beta control panel. If so refer to our wiring diagram 200-60971/01 (also part number for replacement harness)

- Loom is configured differently in the 11-way plug to accommodate the extra wiring.
- Small brown wire (battery sensed alternator feed) fitted with bullet connection beside harness plug.
- Oil pressure and water temperature switch / senders fitted to engine, requiring individual connections for driving gauges and warning lamps.

Note: Water temperature switch/sender (Part number 200-01133)

Large spade is sender connection	(green/blue)
----------------------------------	--------------

Small spade is switch connection	(blue/yellow)
----------------------------------	---------------

Oil pressure switch/sender (Part number 200-62680)

G	Gauge wire	(white/brown)
---	------------	---------------

M	Earth (ground)	(black)
---	----------------	---------

WK	Warning lamp	(green/yellow)
----	--------------	----------------

▼ ELECTRICAL FAULT FINDING - EXTENSION HARNESSSES

Some installations require one of the 'panel extension 11-way connectors' to be removed to allow the cable to be passed through bulkheads etc.

If any panel problems are experienced, after this has been done, visually check all 11-way connections on engine harness to panel extension (**and panel extension to panel on C 'Deluxe'**) to ensure wire colours to each terminal match up to the correct colour in its corresponding terminal.

Extra attention must be given to black (ground) and black/blue (tacho), also brown (switched positive to alternator) and brown/yellow (charge fail) as these connections are harder to distinguish between in poorly lit areas. Whilst doing this check integrity of each connection to ensure terminals have not become damaged. Once checked, re-fit cable tie around each connection to keep them secure.

▼ ELECTRICAL FAULT FINDING - INSULATED EARTH

If your application is wired as insulated earth return and the engine will not operate correctly, always check starter battery negative is connected to the correct terminal on the isolating solenoid.

It should be connected to the terminal which is also used for all the small black wires, **NOT the terminal with the single black wire connected directly to engine ground.**

Spanner Torque Settings

▼ STANDARD NUTS & BOLTS (GRADE/CLASS 4)

ITEM	SIZE	N M	KGf M	LBF FT (FT LBS)
M6	6 MM	7.9 ~ 9.3	0.8 ~ 0.95	5.8 ~ 6.9
M8	8 MM	17.7 ~ 20.6	1.8 ~ 2.1	13.0 ~ 15.2
M10	10 MM	39.2 ~ 45.1	4.0 ~ 4.6	28.9 ~ 33.3
M12	12 MM	62.8 ~ 72.6	6.4 ~ 7.4	46.3 ~ 53.5

▼ SPECIAL NUTS & BOLTS (GRADE/CLASS 7)

ITEM	SIZE	N M	KGf M	LBF FT (FT LBS)
M6	6 MM	9.8 ~ 11.3	1.0 ~ 1.15	7.2 ~ 8.3
M8	8 MM	23.5 ~ 27.5	2.4 ~ 2.8	17.4 ~ 20.3
M10	10 MM	48.1 ~ 55.9	4.9 ~ 5.7	35.4 ~ 41.2
M12	12 MM	77.5 ~ 90.2	7.9 ~ 9.2	57.1 ~ 66.5

▼ BETA 10 TO BETA 25 - SPECIFIC NUTS & BOLTS


ITEM	SIZE X PITCH	N M	KGf M	LBF FT (FT LBS)
CYLINDER HEAD BOLT	M8 X 1.25	37.3 ~ 42.2	3.8 ~ 4.3	27.5 ~ 31.1
CONNECTING ROD BOLT	M7 X 0.75	26.5 ~ 30.4	2.7 ~ 3.1	19.5 ~ 22.4
FLYWHEEL BOLT	M10 X 1.25	53.9 ~ 58.8	5.5 ~ 6.0	39.8 ~ 43.4
MAIN BEARING CAP - BOLT 1	M6 X 1.0	12.7 ~ 15.7	1.3 ~ 1.6	9.4 ~ 11.6
MAIN BEARING CAP - BOLT 2	M7 X 1.0	26.5 ~ 30.4	2.7 ~ 3.1	19.5 ~ 22.4
NOZZLE HOLDER ASSEMBLY	M20 X 1.5	49.0 ~ 68.6	5.0 ~ 7.0	36.2 ~ 50.6
CYLINDER HEAD COVER BOLT	M6 X 1.0	9.8 ~ 11.3	1.0 ~ 1.15	7.2 ~ 8.3
GLOW PLUG	M8 X 1.0	7.8 ~ 14.7	0.8 ~ 1.5	5.8 ~ 10.8
OIL PRESSURE SWITCH	BSP 1/8"	14.7 ~ 19.6	1.5 ~ 2.0	10.8 ~ 14.5
ROCKER ARM BRACKET NUT	M6 X 1.0	9.8 ~ 11.3	1.0 ~ 1.15	7.2 ~ 8.3
IDLE GEAR SHAFT BOLT	M6 X 1.0	9.8 ~ 11.3	1.0 ~ 1.15	7.2 ~ 8.3
CRANKSHAFT BOLT	M12 X 1.5	117.7 ~ 127.5	12.0 ~ 13.0	86.8 ~ 94.0

We recommend that you refer to the Kubota Workshop Manual for detailed maintenance and torque setting information, or contact your local Dealer, or direct to us. We can provide Workshop Manuals as a 'PDF' if required.

Wiring Diagrams - Index

1. Typical starter motor ratings		Page 22
2. Suggested engine starter battery size		Page 22
3. Keyswitch terminations		Page 25
4. Beta 10 - Beta 25 H/E engine harness (40 Amp)	200-05444	Page 57
5. Beta 10 - Beta 25 H/E engine harness (75 Amp)	200-05495	Page 58
6. Diagram of extension harness	200-04588	Page 59
7. Diagram of panel 'A' & cut-out	200-06516 & 200-06305	Page 60 & 61
8. Diagram of panel 'AB' & cut-out	200-06517 & 200-06304	Page 62 & 63
9. Diagram of panel 'ABV' & cut-out	200-06519 & 200-06320	Page 64 & 65
10. Diagram of panel 'ABVW' & cut-out	200-06333 & 200-06331	Page 66 & 67
11. Diagram of panel 'B' & cut-out	200-06520 & 200-06303	Page 68 & 69
12. Diagram of Deluxe panel 'C' & cut-out	200-06518 & 200-06306	Page 70 & 71
13. GA of Beta 10 H/E TMC 40	100-00030	Page 72
14. GA of Beta 14 H/E TMC 40 with Atomic feet	100-01973	Page 73
15. GA of Beta 16 H/E TMC 40	100-06496	Page 74
16. GA of Beta 16 H/E 'Bobtail'	100-08480	Page 75
17. GA of Beta 20 H/E TMC 40	100-99610	Page 76
18. GA of Beta 20 H/E TMC 60	100-08809	Page 77
19. GA of Beta 20 H/E 7° Down angle	100-09154	Page 78
20. GA of Beta 20 H/E Saildrive	100-08836	Page 79
21. GA of Beta 20 K/C PRM80	100-05749	Page 80
22. GA of Beta 20 K/C PRM150	100-07205	Page 81
23. GA of Beta 20 H/E 'Bobtail'	100-09329	Page 82
24. GA of Beta 25 H/E TMC 40	100-06495	Page 83
25. GA of Beta 25 H/E 'V' Drive ZF15 MIV	100-08483	Page 84
26. GA of Beta 25 H/E TMC60A	100-09200	Page 85
27. Split charge relay wiring (65 Amp)	300-62210	Page 86
28. Blocking diode split charge installation	300-62220	Page 87
29. Starter relay wiring - over 4 metres	300-58520	Page 88
30. Electric Fuel Lift Pump	202-06421	Page 89
31. Declaration of Conformity for Recreational Craft		Page 90 & 91
32. Emission durability		Page 92
33. Quick reference parts list		Page 93, 94 & 95
34. Maintenance record and service items		Page 96


Note: Further information and arrangement drawings can be found on our website at: www.betamarine.co.uk



FOR BATTERY CABLE SIZES
REFER TO THE OPERATORS MANUAL

PART FILE NAME: 200-05444 MINI ENGINE WIRING SCHEMATIC (40AMP STD) (U)		TITLE: BETA 10 - BETA 25 HEAT EXCHANGER COOLED ENGINE WIRING SCHEMATIC 40 AMP ALTERNATOR	
REV: 06	DATE: 22/12/2014	SCALE: 1 of 1	NTS
DWG NO: 200-05444	SIZE: A3	DRAWN BY: JLT	CHECKED BY: TW

REV	DESCRIPTION	DATE	APPRO	DRAWN
01	ORIGINALLY DRAWN	22/12/14	TW	JLT



Pin No. - Wire Size - Wire Colour

14 CORE HARNESS

3 - 2.5mm - WHITE/BLACK TRACER

4 - 1mm - BROWN

1 - 2.5mm - BROWN/WHITE TRACER

2 - 2.5mm - WHITE/RED TRACER

11 - 2.5mm - RED

WHITE

9 - 1mm - BROWN/YELLOW TRACER


8 - 1mm - WHITE/BROWN TRACER

7 - 1mm - BLUE/GREEN TRACER

10 - 1mm - BLACK


WHITE

DETAIL A



VIEW A

PIN NO.




VIEW A

PINS 5 AND 6 ARE NOT USED IN THIS ARRANGEMENT. THERE ARE SOME SPARE CORES UNUSED IN THE HARNESS.

11 WAY PLUG

REV	DESCRIPTION	DATE	APP'D	DRAWN	NOTES	TITLE	SCALE	N/A	PAGE	DATE	REV
						FOR PART LIST AND PANEL SIZE SEE DRAWING 200-06305 PANEL PART NUMBER 200-00852	A4	N/A	1 of 1	15/05/05	
						WIRING SCHEMATIC FOR A PANEL (SIMPLE) AFTER MAY 2005					
						DIMENSIONS IN MM (INCH) DO NOT SCALE					
						BETA MARINE LTD. DAVY WAY WATERWELLS QUEDGELEY, GLOUCESTER GL2 2AD UK					
						TEL +44 (0)1452 723492 FAX +44 (0)1452 883742					
						DRAWN BY:- TW					
						CHECKED BY:- DM					




REV	DESCRIPTION	DATE	APP'D	DRAWN	NOTES
01	TACHO	22/04/11	DM	TW	


TITLE		WIRING SCHEMATIC FOR B PANEL AFTER MAY 2011	
SIZE	DWG NO.	SCALE	PAGE
A4	200-06520	N/A	1 of 1
DRAWN BY:-	CHECKED BY:-	DATE	REV
TW	DM	16/05/05	01

DIMENSIONS IN MM (INCH)
DO NOT SCALE

BETA MARINE
BETA MARINE LTD.
DAVY WAY, WATERWELLS,
QUEDGELEY, GLOUCESTER
GL2 2AD UK
TEL +44 (0)1452 723492 FAX +44 (0)1452 883742



REV	DESCRIPTION	DATE	APPD	DRAWN	NOTES	TITLE
01	NEW TANK, PUMP AND PIPE	08/1/14	LT	TW		BETA 16 HEAT EXCHANGE TMC40 GEARBOX
DIMENSIONS IN MM (INCH) DO NOT SCALE						
PART FILE NAME: BZ602.02 HEAT EXCHANGE TMC40.asm						
BETA MARINE BETA MARINE LTD. DAVY WAY, WATERWELLS, QUEDGELEY, GLOUCESTER GL2 2AD UK TEL +44 (0)1452 723492 FAX +44 (0)1452 883742						
DRAWN BY: TW		SIZE: A4		DWG NO: 100-06496		REV: 01
CHECKED BY: LT		SCALE: 1 of 1		PAGE: 1 of 1		DATE: 08/01/2014




REV	DESCRIPTION	DATE	APPD	DRAWN	NOTES
01					


TITLE: BETA 16 HEAT EXCHANGE BOB TAIL					
DRAWN BY: TW	SIZE: A4	DWG NO: 100-08480	REV: 00		
CHECKED BY: LT	SCALE: NTS	PAGE: 1 of 1	DATE: 30/09/2008		

DIMENSIONS IN MM (INCH) DO NOT SCALE
 PART FILE NAME: 100-08480 BZ602 HE BOB TAIL.asm
 BETA MARINE LTD.
 DANBY WAY
 WATERWELLS
 QUEDSELEY,
 GLOUCESTER, GL2 2AD, UK
 TEL: (01452) 729482
 FAX: (01452) 729482











REV	DESCRIPTION	DATE	APPD	DRAWN	NOTES	TITLE
01						BETA 20 HEAT EXCHANGE TMC60 USE WITH LH PROP
DIMENSIONS IN MM (INCH) DO NOT SCALE BETA MARINE TEL: (01452) 725492 FAX: (01452) 728916 BETA MARINE LTD, DAVY WAY, QUEDSBELLY, GLOUCESTER, GL2 2AD, UK						
DRAWN BY: TW		CHECKED BY: LT		SCALE: NTS		PAGE: 1 of 1
DWG NO: 100-08809		REV: 00		DATE: 19/11/2009		




REV	DESCRIPTION	DATE	APPD	DRAWN	MATL	FINISH	UNTOLERANCED DIMS: ± 0.25	TITLE:
01								BETA 20 HEAT EXCHANGE TMC60A GEARBOX
								PART FILE NAME: 100-09154_beta20_he_tmc60a.dft
								SCALE: NTS DATE CREATED: 28/01/2011
								DRAWN BY: TW SIZE: A4
								CHECKED BY: LT PART NUMBER: 100-09154
								REV 00
								PAGE 1 of 1

DIMENSIONS IN MM (INCH)
 DO NOT SCALE

BETA MARINE
 BETA MARINE LTD,
 DAVY WAY,
 WATERWELLS,
 QUODDSELLEY,
 GLOUCESTER, GL2 2AD, UK
 TEL: (01452) 723492 FAX: (01452) 729916




REV	DESCRIPTION	DATE	APPD	DRAWN	NOTES	TITLE
01						BETA 20 HEAT EXCHANGE BOB TAIL
						DIMENSIONS IN MM (INCH) DO NOT SCALE BETA MARINE TEL: (01452) 725492 FAX: (01452) 726916 PART FILE NAME: BETA 20 HE BOB TAIL 100-09329.asm DRAWN BY: TW CHECKED BY: LT BETA MARINE LTD. DAVY WAY, WATERWELLS, GLOUCESTER, GL2 2AD, UK
				SIZE A4	DWG NO. 100-09329	REV 00
				SCALE	NTS	PAGE 1 of 1
						DATE 15/11/2011



REV	DESCRIPTION	DATE	APP'D	DRAWN	NOTES
01	CALDRIFERS AND SHALLOW SUMP NEW HEATER TANK, AIR FILTER AND ALTERNATOR	7/10/06 10/9/12		TW TW	

TITLE: BETA 25 HEAT EXCHANGE TMC40 GEARBOX		DRAWN BY: TW		SIZE: A4	DWG NO: 100-06495	REV: 02
PART FILE NAME: 100-06495 01 BD602 HE TMC40.asst		CHECKED BY: LT		SCALE: NTS	PAGE: 1 of 1	DATE: 11/09/2012
DIMENSIONS IN MM (INCH) DO NOT SCALE BETA MARINE BETA MARINE LTD. DAVEY WAY WATERWELLS QUEDGELEY, GLOUCESTER, GL2 2AD, UK TEL: (01452) 723492 FAX: (01452) 729916						



NOTES_

IF BATTERY ISOLATOR(S) ARE FITTED THEY MUST BE CLOSED WHEN ENGINE IS STARTED AND RUNNING. THEY MUST NOT BE OPERATED WHEN THE ENGINE IS RUNNING AS THIS WILL DAMAGE THE ALTERNATOR.

BATTERY LEADS MUST BE INCREASED IN CSA FOR RUNS OVER 2M. CONSULT BETA. CABLES SHOWN BY DASHED LINES ARE CUSTOMER SUPPLY. RECOMMENDED MINIMUM CSA'S SHOWN.




WE RECOMMEND THE USE OF MULTISTRANDED CABLE TO BS 6862 PT 1. - 25mm - 196/0.4(EPR/CSP) 6mm - 84/0.3 1mm - 14/0.3

BETA SPLIT CHARGE RELAY PT NO - 200-57640
 BETA BATT. ISOLATOR SWITCH PT NO - 200-62200
 REFER ALSO TO SPECIFIC ENGINE WIRING DIAGRAM(S)
 ALSO BETA MARINE NOTES "DUAL BATTERY CHARGING SYSTEMS".
 BATTERY LEADS, SWITCHES AND 33RA RELAY ARE OPTIONAL EXTRAS AND ARE ONLY SUPPLIED WHEN SPECIFICALLY ORDERED.

REV	DESCRIPTION	DATE	APP'D	NOTES	COMPLETE UNIT
01	REDRAWN ON CAD	01.08.2001	TW	FOR BLOCKING DIODE SYSTEM REFER TO DRAWING 300-62220. DRAWINGS 200-02189, 300-00212 SHEETS 1, 2 AND 3 ALSO RELATE TO SPLIT CHARGE AND INSULATED SYSTEMS.	TYPICAL INSTALLATION FOR SPLIT CHARGE DUAL BATTERY SYSTEM, MACHINE SENSED ALTERNATORS.
02	MINOR MODIFICATIONS AND NOTES	10.10.2001	PAG		TITLE
03	CHANGED STD ALTERNATOR	05.06.2003	DM	(ISSUE 02+ OF THIS DRAWING ALSO REPLACES 300-97720).	SPLIT CHARGE RELAY INSTALLATION.
04	CHANGED NOTES	15.12.2005	DM		DWG NO. 300-62210
					DATE OCTOBER 1997
					REV 04
					SHEET 1 OF 1

BETA MARINE

DRAWN BY:- **PAG**
 CHECKED BY:-



NOTES -
IF BATTERY ISOLATOR(S) ARE FITTED THEY MUST BE CLOSED WHEN ENGINE IS STARTED AND RUNNING. THEY MUST NOT BE OPERATED WHEN THE ENGINE IS RUNNING AS THIS WILL DAMAGE THE ALTERNATOR.
BATTERY LEADS MUST BE INCREASED IN CSA FOR RUNS OVER 2M. CONSULT BETA. CABLES SHOWN BY DASHED LINES ARE CUSTOMER SUPPLY. RECOMMENDED MINIMUM CSA'S SHOWN.
BLOCKING DIODE MUST BE SIZED TO COPE WITH THE FULL ALTERNATOR OUTPUT.

WE RECOMMEND THE USE OF MULTISTRANDED CABLE TO BS 6882 PT 1 - 25mm - 196/0.4(EPR/CSP) 6mm - 84/0.3 1mm - 14/0.3
BETA SPLIT CHARGE RELAY PT NO - 200-67640
BETA BATT. ISOLATOR SWITCH PT NO - 200-62200
REFER ALSO TO SPECIFIC ENGINE WIRING DIAGRAM(S)
ALSO BETA MARINE NOTES "DUAL BATTERY CHARGING SYSTEMS".
BATTERY LEADS: SWITCHES AND RELAYS ARE OPTIONAL EXTRAS AND ARE ONLY SUPPLIED WHEN SPECIFICALLY ORDERED.

NOTE RE 28RA RELAY. THIS RELAY IS TO BE INSTALLED IF DOMESTIC BATTERIES ARE TO BE SENSED. IT CAN BE OMITTED AND THE ORIGINAL SMALL BROWN RETAINED TO THE PANEL, IN WHICH CASE THE ALTERNATOR WILL SENSE THE STARTER BATTERY.

REV	DESCRIPTION	DATE	APP'D	NOTES	COMPLETE UNIT
02	REDRAWN ON CAD	15.10.2001	PAG	FOR SPLIT CHARGE RELAY SYSTEM REFER TO DRAWING 300-62210. DRAWING 200-02189 MAY ALSO BE OF ASSISTANCE.	TYPICAL INSTALLATION FOR SPLIT CHARGE DUAL BATTERY SYSTEM, BATTERY SENSED ALTERNATORS.
03	SHOWN BATTERY CABLE IN DASHED	15.02.05	TW	(ISSUE 02+ OF THIS DRAWING ALSO REPLACES 300-97720).	BLOCKING DIODE SPLIT CHARGE INSTALLATION.
04	ADDED MISSING - BATTERY CONECTION	01.12.05	TW		
05	CHANGED ALT & SHOWN 3 PIN ALT	15.12.05	TW		
06	TEXT ON LARGE BROWN	21.08.07	TW		
07	BETA 16 AND 25 ALT	10.11.08	TW		
				DRAWN BY:- PAG	DWG NO. 300-62220
				CHECKED BY:-	DATE OCTOBER 1997
					REV 05
					SHEET 1 OF 1



Declaration of Conformity for Recreational Craft Propulsion Engine with the Exhaust emission requirements of Directive 94/25/EC as amended by 2003/44/EC
(Completed by manufacturer of inboard engines without integral exhaust)

Name of engine manufacturer: Beta Marine Limited
Street: Davy Way, Waterwells **Town:** Quedgeley, Gloucestershire
Post Code: GL2 2AD **Country:** U.K.

Name of Authorised Representative: not applicable

Name of Notified Body for exhaust emission assessment: DNV GL - Maritime
Address: Brooktorkai 18 **Town:** Hamburg **Post Code:** 20457 **Country:** Germany **ID Number:** 0098

Conformity assessment module used for exhaust emissions: B+C

DESCRIPTION OF ENGINES AND ESSENTIAL REQUIREMENTS

Engine type: Inboard engine.
 Fuel type: Diesel gas oil JIS K2204:1997 or equal.
 Combustion cycle: 4-stroke.

IDENTIFICATION OF ENGINE(S) COVERED BY THIS DECLARATION OF CONFORMITY

Name of engine model	Unique Engine family code	EC Type examination certificate number
Beta 10	5KBXL.719KCB	35559-06 HH
Beta 14 BZ482	5KBXL.719KCB	35559-06 HH
Beta 20 BD722	5KBXL.719KCB	35559-06 HH

Essential requirements	Standards	Other normative document method	Technical file	Please specify in more detail (*=mandatory standard)
Annex I.B – Exhaust Emissions				
engine identification	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	2033/44 annex 1B para 1.
exhaust emission requirements	<input checked="" type="checkbox"/> *	<input type="checkbox"/>	<input type="checkbox"/>	*EN ISO 8178 – 1 : 1996
durability	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	2033/44 annex 1B para 3.
owner's manual	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	2033/44 annex 1B para 4.
Annex I.C – Noise Emissions	see Declaration of Conformity of the craft in which the engine(s) has (have) been installed			

This declaration of conformity is issued under the sole responsibility of the manufacturer. I declare on behalf of the engine manufacturer that the engine(s) is (are) in conformity with the type(s) for which above mentioned EC type-examination or type approval certificate(s) has(have) been issued and will meet the exhaust emission requirements of Directive 94/25/EC as amended by Directive 2003/44/EC when installed in a recreational craft, in accordance with the engine manufacturer's supplied instructions and that this (these) engine(s) must not be put into service until the recreational craft into which it is (they are) to be installed has been declared in conformity with the relevant provisions of the above mentioned Directives.

Name J. A. Growcoot Signature and title:  C.E.O.
 (identification of the person empowered to sign on behalf of the engine manufacturer)

Date: (yr/month/day) 2008 / 11 /04 Quedgeley, Gloucestershire
 Certificate 3GL Revision 04, 2014/06/24, Notified Body references updated to DNV GL.

Declaration of Conformity for Recreational Craft Propulsion Engine with the Exhaust emission requirements of Directive 94/25/EC as amended by 2003/44/EC

(Completed by manufacturer of inboard engines without integral exhaust)

Name of engine manufacturer: Beta Marine Limited
Street: Davy Way, Waterwells **Town:** Quedgeley, Gloucestershire
Post Code: GL2 2AD **Country:** U.K.

Engine type-approved according to: Stage II of Directive 97/68/EC
 (Name of Notified Body for exhaust emission assessment: TUV Kraftfahrt GmbH, Flensburg, Germany accreditation number DAR KBA-P 00010-96)

DESCRIPTION OF ENGINES AND ESSENTIAL REQUIREMENTS

Engine type: Inboard engine.
 Fuel type: Diesel gas oil JIS K2204:1997 or equal.
 Combustion cycle: 4-stroke.

ENGINE(S) COVERED BY THIS DECLARATION	
Engine models and engine family names:	EC Type certificate number (exhaust)
BZ602 Beta 16 BD902 Beta 25 3KBXL898KCD	e1*97/68DA*2002/88*0266*00
BD1105 Beta 30 BV1505 Beta 35 BV1505 Beta 38 3KBXL01.5BCD	e1*97/68DA*2004/26KA*0164*03 e1*97/68DA*2006/105KA*0164*04
BV1505T Beta 45 3KBXL01.5BAD	e1*97/68DA*2006/105KA*0160*02

ENGINE(S) COVERED BY THIS DECLARATION	
Engine models and engine family names:	EC Type certificate number (exhaust)
BV2003 Beta 43 BV2203 Beta 50 YKBXL02.2FCD	e1*97/68DA*2004/26KA*0072*09 e1*97/68DA*2004/105KA*0072*13
BV2403 Beta 60 YKBXL02.4FCD	e1*97/68DA*2004/26KA*0073*05 e1*97/68DA*2006/105KA*0073*09
BV2607 Beta 70 8KBXL02.6EAD	e1*97/68JA*2004/26*0494*00
BV3600 Beta 75 7KBXL03.6BCD	e1*97/68JA*2004/26*0430*00
BV3600T 3KBXL03.3BAD	e1*97/68GA*2001/63*0144*00
BV3307 Beta 85 8KBXL03.3CAD	e1*97/68JA*2004/26*0460*00
BV3800 Beta 90 3KBXL03.8ACD	e1*97/68GA*2001/63*0155*00
BV3800T Beta 105 3KBXL03.8ACD	e1*97/68JA*2004/26*0418*00

Essential requirements	Standards Used	Other normative document used	See technical file
Annex I.B – Exhaust Emissions			
engine identification	N/A	2033/44 annex 1B para 1.	QA025
exhaust emission requirements	N/A	2003/44 para 16, L214/19	EC type certificate has its own technical file.
durability	N/A	2033/44 annex 1B para 3.	QA033
owner's manual	BS EN ISO 10240	2033/44 annex 1B para 4.	N/A
Annex I.C – Noise Emissions	see craft manufacturer's Declaration of Conformity		

I declare on behalf of the engine manufacturer that the engine(s) will meet the exhaust emission requirements of Directive 94/25/EC as amended by Directive 2003/44/EC when installed in a recreational craft, in accordance with the engine manufacturer's supplied instructions and that this (these) engine(s) must not be put into service until the recreational craft into which it is (they are) to be installed has been declared in conformity with the relevant provisions of the above mentioned Directive

Name J. A. Growcoot

Signature and title:

C.E.O.

(identification of the person empowered to sign on behalf of the engine manufacturer)

Date: (yr/month/day) 2008 / 10 / 22 Quedgeley, Gloucestershire

Certificate 2.06 Revision 09, 2015/06/08, latest models/approvals listed.

Emission Durability

IN RESPECT TO THE RECREATIONAL CRAFT DIRECTIVE 94/25/EC AND AMENDMENT 2003/44/EC ANNEX 1, B3.

The engine must be installed, maintained and operated within the parameters detailed in the Operator's Maintenance Manual. Maintenance must use approved materials, parts and consumables. Should the engine lie unused for a period in excess of 6 months it must be inhibited otherwise it will deteriorate with resulting decrease in performance. See also the Winterising and Laying Up procedures in the Operator's Maintenance Manual.

The fuel settings of the diesel injection system must not be tampered with otherwise the guarantee will be invalid and the performance may fall outside prescribed limit. Such adjustment cannot be allowed under the terms of the emission certification.

Performance of the engine depends upon the use of correct fuels, lubricants and inhibitors. These are fully detailed in the Operator's Maintenance Manual.

Particular attention must be paid to the installation with respect to the exhaust system. The system must be designed so that water cannot back feed into the engine. The run must be such that the back pressure at the engine manifold does not exceed the level detailed in the Operator's Maintenance Manual. Wet, water injected, exhaust systems must be at least the bore mentioned in the Operator's Maintenance Manual and should the run be excessive this bore must be increased accordingly. Back pressure is measured at the outlet of the engine manifold before the water injection bend or dry bellows.

Our experience since 1987 has shown that properly installed and maintained engines hold their performance without major mishap even when running hours exceed those mentioned in the Recreational Craft Directive. It is the owners / users responsibility to ensure that the engine continues to function properly and any malfunction must be immediately investigated. The Trouble Shooting section as detailed in the Operator's Maintenance Manual is particularly helpful in this respect. Engine performance, especially with respect to erratic running, exhaust condition, low power output and high oil consumption are indications of engine conditions that may result in emissions outside the prescribed limits and must therefore be investigated and rectified immediately.

Quick Reference Parts List

Heat Exchanger and Keel Cooled **Beta 10, Beta 14, Beta 16, Beta 20 & Beta 25** engines. In all cases please quote **Beta Marine WOC “K” number** and engine type.

Description	Part Number	Qty per Engine
Drive Plate 22-B-60 - PRM / ZF	206-91950	1
Drive Plate 22-B-4 - TMC / PRM / ZF	206-97041	1
Flexible Mountings (Trelleborg Type)	213-93440	4
Rocker Cover Gasket - Beta 14	600-01055	1
Rocker Cover Gasket - Beta 16	600-05467	1
Rocker Cover Gasket - Beta 20	600-00607	1
Rocker Cover Gasket - Beta 25	600-05468	1
Head Gasket - Beta 10 / Beta 14	600-00409	1
Head Gasket - Beta 16	600-05469	1
Head Gasket - Beta 20	600-01562	1
Head Gasket - Beta 25	600-05470	1
Top Gasket Set - Beta 14	600-00383	1
Top Gasket Set - Beta 16	600-05471	1
Top Gasket Set - Beta 20	600-00395	1
Top Gasket Set - Beta 25	600-05472	1
Lower Gasket Set - Beta 14	600-01056	1
Lower Gasket Set - Beta 16	600-05473	1
Lower Gasket Set - Beta 20	600-00394	1
Lower Gasket Set - Beta 25	600-05474	1
Operators Maintenance Manual	221-02887	1
Workshop Manual - Beta10, Beta14 & Beta20	600-00756	1
Workshop Manual - Beta16 & Beta25	600-06242	1
Spare Parts Manual - Beta10 & Beta14	600-02437	1
Spare Parts Manual - Beta16	600-05476	1
Spare Parts Manual - Beta20	600-02438	1
Spare Parts Manual - Beta25	600-05477	1

Note: the above part numbers are suitable for earth return installations only (where battery negative cable is connected directly to engine ground). For insulated earth (where battery negative cable is isolated from engine ground) different harnesses, alternators, switches for oil pressure and engine temperature will be required.

Quick Reference Parts List

Heat Exchanger and Keel Cooled **Beta 10, Beta 14, Beta 16, Beta 20 & Beta 25** engines. In all cases please quote **Beta Marine WOC "K" number** and engine type.

Description	Part Number	Qty per Engine
Alternator 65 Amp (Internal Fan)	600-04989	1
Panel A (Standard)	AK/2AS/KS01	1
Panel ABV with Tachometer	AK/2ABV/KS01	1
Panel ABVW with Tachometer	AK/2ABVW/KS01	1
Panel B with Tachometer and Gauge	AK/2BT/KS02	1
Panel C with Tachometer and Three Gauges	AK/2CD/KS01	1
Control Panel Standard Key (Silver) - To June 2008	600-00058	2
Control Panel Standard Key (Silver) - From June 2008	600-00058/01	2
Control Panel Key Switch (Silver) - To June 2008	600-00057	1
Control Panel Key Switch (Silver) - From June 2008	600-00057/01	1
Control Panel Stop Button (and Heat & Start on ABVW)	200-00072	1
Tachometer - 0 to 4000rpm with Digital Hour Counter	200-02373	1
Water Temperature Switch Gauge (B & C Panels)	200-96200	1
Oil Pressure Switch Gauge (C Panels Only)	200-96190	1
Voltmeter (C Panels Only)	200-96210	1
Green Power On Indicator Lamp and Retaining Clip	200-04656	1
Red Warning Indicator Lamp and Retaining Clip	200-04657	3 or 4
Alarm Board	200-04655	1
Relay 12 Volt 40A (28Ra) - Fitted to Rear of Panels	200-87020	1
Stop Solenoid (Energised to Stop Fuel)	600-81950	1
Fuse (Blade) 40 Amp	200-00959	1
Standard Engine Harness	200-98380/01	1
65 Amp Alternator Sub Loom (External Fan)	200-01196	1
1m Panel Extension Loom	200-04588/01	1
2m Panel Extension Loom	200-04588/02	1
3m Panel Extension Loom	200-04588/03	1
4m Panel Extension Loom	200-04588/04	1
Water Temperature Switch (Panel A, ABV & ABVW) (Only Beta10, Beta14 or Beta20 to March 2007)	200-01133	1
Water Temperature Switch with Single Terminal (Panel A, ABV & ABVW) (Beta16 & Beta25 and standard from March 2007)	600-62820	1
Water Temperature Sender 5/8UNF (Panel C & B)	200-94360	1
Water Temperature Sender 1/8NPT (Panel C & B) - From April 2011	200-08248	1
Oil Pressure Switch (Panel A, ABV, ABVW, & B)	600-62670	1
Oil Pressure Sender (Panel C)	200-94350	1
Standard 50mm Water Injection Exhaust Bend	202-02458	1
5" High Rise 50mm Water Injection Exhaust Bend	202-92400/22	1
Exhaust Bend Gasket	212-09070	1

Quick Reference Parts List

Heat Exchanger and Keel Cooled **Beta 10, Beta 14, Beta 16, Beta 20 & Beta 25** engines. In all cases please quote **Beta Marine WOC "K" number** and engine type.

Description	Part Number	Qty per Engine
Wasting Zinc Anode	209-61840	1
Heat Exchanger O Ring (Header with Single Bolt Endcap)	209-80110	2
Heat Exchanger O Ring (2011 Header with 3 Bolt Endcap)	212-07273	2
Pressure Cap - 95kPa - 15psl	209-80130	1
Thermostat (Beta10, Beta14 & Beta20 Only)	600-59290	1
Thermostat (Beta16 & Beta25 Only)	600-72450	1
Thermostat Gasket (Beta10, Beta14 & Beta20 Only)	600-62590	1
Thermostat Gasket (Beta16 & Beta25 Only)	600-80490	1
Fuel Filter	211-60210	1
Air Filter Element - March 2011 (3 Clamp Style - Steel)	211-62950	1
Air Filter Element - From March 2011 (Plastic Body)	211-08132	1
Lubricating Oil Filter	211-63760	1
Sump Pump	210-80061	1
Sump Pump Clamp	212-00793	2
Dip Stick - Extended	600-96280	1
Beta Marine Sea Water Pump (From June 2013)	207-08922	1
Sea Water Pump Clamp	202-08924	1
Impeller Kit (Includes O Ring)	207-09041	1
Seal Kit	207-09228	1
Shaft Kit	207-09929	1
Johnson 6 Screw Sea Water Pump (From July 2006 - June 2013)	207-61500/01	1
Impeller Kit Johnson 6 Screw (Includes Gasket, Etc.)	207-05355	1
Cover Plate Johnson 6 Screw	207-05478	1
Cover Plate Bolt Johnson 6 Screw	207-05479	6
Fuel Lift Pump (Beta10, Beta14 & Beta20 Only)	600-65470	1
Fuel Lift Pump (Beta16 & Beta25 Only)	AK/MINI/9&6/F01	
Fuel Lift Pump Gasket	600-00065	1
Belt - Standard "PolyVee" - From Jan 2011 with 2011 Spec H/E	212-05074	<i>Correctly Select A Belt</i>
Belt - Standard "Vee" 40 Amp - From Jan 2011 with 2011 Spec H/E	214-00126	<i>Correctly Select A Belt</i>
Belt - Standard "Vee" 40 Amp - To Dec 2010	600-63080	<i>Correctly Select A Belt</i>
Belt - PolyVee 40 Amp 4PK900 (NOT Beta25) - To Dec 2010	214-04360	<i>Correctly Select A Belt</i>
Belt - PolyVee 40 Amp 4PK913 (Beta25) - To Dec 2010	212-05074	<i>Correctly Select A Belt</i>
Belt - 65 Amp Alt. Beta14 / Beta20 4PK950 (Ext. Fan) - To Dec 2010	214-03235	<i>Correctly Select A Belt</i>
Belt - 65 Amp Alt. Beta16 4PK900 (Internal Fan) - To Dec 2010	214-04360	<i>Correctly Select A Belt</i>
Belt - 65 Amp Alt. Beta25 4PK913 (Internal Fan) - To Dec 2010	212-05074	<i>Correctly Select A Belt</i>
Alternator 40 Amp	600-80010	1
Alternator 75 Amp (Internal Fan) - 2011 Spec H/E	200-07338	1
Alternator 65 Amp (External Fan)	200-01155	1

Service Record

	Service	Date	Responsible	
1	Commissioned			
2	First 25 hours			
3	First 50 hours			
4	Every 150 hours with shallow sump			
5	Every Year / Every 250 hours if sooner			
6				
7				
8				
9	Every 750 hours			
10				
11				
12				
13				
14				
15				
16				

Fig 2 Typical Fuel Supply & Leak Off







Fig 3 Typical Keel Cooling System

Heat Exchanger Cooled
10 to 150bhp



Keel Cooled
10 to 150bhp



Marine Generating Sets
4 to 40kVA



Sail Drives
13.5 to 56bhp



BETA MARINE

Beta Marine Limited
Davy Way, Waterwells
Quedgeley, Gloucester
GL2 2AD, UK.

Tel: 01452 723492
Fax: 01452 883742
Email: sales@betamarine.co.uk
www.betamarine.co.uk

Ref: 1590, May 2015



Marine Generating Sets
30 to 1000kVA